



1:laser print 2:ESN-Serial Numbering VVVVVVVWWDLLSSSSS 3:The tolerance is +/- 0.15

3. The toresance is +r-u.12

WVVVVVV is Product code (7 digits) assigned by Nokia, updated in PDM

Yis a code for production yapt as one number (3=2003, 4=2004, 5=2005, etc.)

WW is sweet code (01-53)

D is weekday as one number (1=Monday, 2=Tuseday, etc.).

Li is code for production line as two numbers (0.1,2.3...99)

For enhancements.

SSSSSS (6 digits) is running serial number starting from separate specified number (e.g. "300001") and restarting from "000000" after "999999". Restart takes place every day.