

IC Warning

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada.

Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.



We **LOVE** our consumers!
Get to know us at:

www.summerinfant.com

Summer Infant stands behind all of its products. If you are not completely satisfied or have any questions, please contact our Consumer Relations Team between 8AM - 6PM EST at **1-800-268-6237** or www.summerinfant.com/contact (For Europe call +44 (0) 144 250 5000 or customerserviceuk@summerinfant.com)

connect with us:   

© 2013 Summer Infant, Inc.
Colors and styles may vary.
Please retain information
for future reference.
MADE IN CHINA. 6/13

Apple®, iPhone®, iPad®, and iPod® are trademarks of Apple Inc. registered in the U.S. and other countries. Android™ is a trademark of Google Inc. Google Play™ is a trademark of Google Inc.

Summer Infant, Inc.
1275 Park East Drive
Woonsocket, RI 02895 USA
1-800-268-6237

Summer Infant Europe, Ltd.
First Floor North Wing, Focus 31
Cleveland Road, Hemel Hempstead
HP2 7BW UK
+44 (0) 144 250 5000



28640


Please read the following instructions and warnings carefully. Keep this instruction manual for future reference.

Tools required:
screwdriver and drill (not included)

For technical support see back page.

Adult use only.

BC  **WARNING:**
Adult assembly required.
Keep small parts away from children when assembling.



INSTRUCTION MANUAL

BABY TOUCH™ WIFI VIDEO MONITOR & INTERNET VIEWING SYSTEM

! WARNING:
STRANGULATION HAZARD - Children have STRANGLED in cords. Keep this cord out of reach of children (more than 3 feet (0.9 m) away from the crib). Use enclosed Security Clips to help secure cord away from baby's reach. Never use extension cords with AC Adapters. Only use the AC Adapters provided.



System Requirements: You need a broadband Internet connection (cable/DSL) with recommended upload speed of 300 bps and a wireless router or a cable/DSL modem. You must have a smartphone or tablet with Android 2.3.4. or higher or Apple iOS 5.0 or higher for setup.

WARNING:

THIS PRODUCT CANNOT REPLACE RESPONSIBLE ADULT SUPERVISION.

- **STRANGULATION HAZARD** - Children have STRANGLED in cords. Keep this cord out of reach of children (more than 3 feet (0.9 m) away from the crib). Use enclosed security clips to help secure cord away from baby's reach. Never use extension cords with AC adapters. Only use the AC adapters provided.
- When an AC adapter is plugged into an electrical outlet, do not touch the exposed end.
- Test monitor before first use, periodically, and when changing location of the camera.
- Do not use monitor near water (such as bathtub, sink, etc.).
- Keep monitor away from heat sources (such as stoves, radiators, etc.).
- Make sure there is proper ventilation around all monitor components. Do not place on sofas, cushions, beds, etc. which may block ventilation.
- Nursery monitors use public airwaves to transmit signals. This monitor may pick up signals from other monitors or similar devices and signals broadcast by this monitor may be picked up by other receivers.
- This product is not a toy. Do not allow children to play with it.
- This product contains small parts. Adult assembly required. Exercise care when unpacking and assembling the product.

BATTERY WARNING:

- Use only the original rechargeable batteries provided. Please contact Summer Infant, Inc. for replacement batteries. Contact information can be found at the end of these instructions or on the battery itself.
- Do not mix old and new batteries.
- Do not mix alkaline, standard, or rechargeable batteries.
- Batteries are to be inserted with correct polarity.
- Clean battery and product contacts prior to battery installation.
- Do not short-circuit supply terminals.
- Only the recommended batteries or equivalent are to be used, volts and size.
- Remove batteries when product is stored for long periods of time or when batteries are exhausted.
- Dispose of exhausted batteries properly.
- Do not recharge non-rechargeable batteries.
- Rechargeable batteries are only to be charged under adult supervision.
- Keep all batteries away from children.

If you experience a problem that is not noted in this manual, please do not return the product to the store. Our Customer Service Department may have a simple solution to your problem. Please contact us at 1-800-268-6237 or email us at www.summerinfant.com/contact

FCC Information

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Changes or modifications not expressly approved by Summer Infant may void the users authority to operate this equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiver
- Increase the separation between the equipment and the receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

CAUTION: 1. To comply with FCC/IC RF exposure compliance requirements, a separation distance of at least 20 cm must be maintained between the antenna of this device and all persons. 2. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Summer Infant, Inc. Monitor Warranty Policy


Summer Infant, Inc. will repair or replace (at our option) your unit free of charge for 12 months from the date of purchase if the unit is defective in workmanship or materials. To claim your repair/replacement, the product must be returned to Summer Infant along with a copy of the original purchase receipt. In the absence of the purchase receipt, the warranty will be 12 months from the date of manufacture. This warranty does not apply to normal wear or damage from misuse, abuse, improper storage and handling, installation, accident, unauthorized repair or alteration. Please contact our Customer Service Department by phone at 1-800-268-6237 or via e-mail at www.summerinfant.com/contact for details.




IMPORTANT SAFETY INSTRUCTIONS

- 1) Read Instructions - All the safety and operating instructions should be read before the product is operated.
- 2) Retain Instructions - The safety and operating instructions should be retained for future reference.
- 3) Heed Warnings - All warnings on the product and in the operating instructions should be adhered to.
- 4) Follow Instructions - All operating and use instructions should be followed.
- 5) Cleaning - Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
- 6) Attachments - Do not use attachments not recommended by the product manufacturer as they may cause hazards.
- 7) Water and Moisture - Do not use this product near water - for example, near a bath tub, wash bowl, kitchen sink, or laundry tub; in a wet basement; or near a swimming pool; and the like.
- 8) Accessories - Do not place this product on an unstable cart, stand, tripod, bracket, or table. The product may fall, causing serious injury to a child or adult, and serious damage to the product. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the product. Any mounting of the product should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.
- 9) Ventilation - Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from overheating, and these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surfaces. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.
- 10) Power Sources - This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company. For products intended to operate from battery power, or other sources, refer to the operating instructions.
- 11) Power-Cord Protection - Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the product.
- 12) Power Lines - An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.
- 13) Overloading - Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.
- 14) Object and Liquid Entry - Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.
- 15) Servicing - Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.
- 16) Damage Requiring Service - Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:
 - a) When the power-supply cord or plug is damaged,
 - b) If liquid has been spilled, or objects have fallen into the product,
 - c) If the product has been exposed to rain or water,
 - d) If the product does not operate normally by following the operating instructions. Adjusting only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation,
 - e) If the product has been dropped or damaged in any way, and;
 - f) When the product exhibits a distinct change in performance .
- 17) Replacement Parts - When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.
- 18) Safety Check - Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.
- 19) Wall or Ceiling Mounting - The product should be mounted to a wall or ceiling only as recommended by the manufacturer.
- 20) Heat - The product should be situated away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.


components:




hardware:



features (monitor):



features (camera):




initial APP setup:

1



Connect your device (phone or tablet) to your home WiFi network and download the free APP for your Apple® or Android™ phone or tablet.



**SEARCH FOR:
"SUMMER LINK
WIFI"**



iPhone®, iPod®, iPad® **iOS 5.0 or higher required**

Android™ phone or tablet **Android 2.3.4 or higher required**


2a

Open your Summer Link WiFi APP and follow the instructions on screen to complete signup.




2b

Locate the QR code on the bottom of your camera to complete setup. Note: No QR code scanner required!




3

Power on the camera. The four green LEDs will circle while configuring to your home WiFi network



4

Follow steps on screen to complete activation and you're ready to start viewing your little one!



4

add a Link WiFi camera:

The **Baby Touch WiFi Video Monitor & Internet Viewing System** accepts up to 4 cameras, and enables parents to monitor more than one child or room in the home. The expandable system gives parents the ability to easily and conveniently keep an eye on things from wherever they are, anytime.


The compatible extra camera is the **Baby Link WiFi Internet Viewing Camera** (item #28660).



Baby Link WiFi Camera



Two camera system for a dual splitscreen view.



Four camera system enables the 4-way splitscreen view.

replacement parts and product registration:

If you need to order a replacement part, you can contact our Consumer Relations Department at 1-888-268-6237 or via email at: www.summerinfant.com/contact

Rechargeable battery: item #02800-10
Handheld AC Adapter: item # 28450-13
Camera AC Adapter: item # 02000-05

To register your product, visit:

www.summerinfant.com/product-registration/product-registration-form

13

problem solving & troubleshooting:

IN-HOME HANDHELD MONITOR:

No picture or sound on monitor:

- Make sure the monitor is turned on.
- Make sure the AC adapters are plugged into the AC adapter jack on the handheld monitor and the camera and to electrical outlets.
- Make sure the electrical outlets are working.
- Make sure the monitor and camera are synced (refer to "syncing monitor and camera" section on page 7).

Sound but no picture on monitor:

- Press the Video On/Off button to turn on from Power Save Mode.
- Adjust the brightness using the Brightness Control toggle on handheld.
- Test reception by moving the monitor and/or camera to different locations.

Picture but no sound:

- Adjust the volume using the Volume Control on handheld.

Picture not clear:

- Position the monitor closer to the camera, if necessary.
- Move the monitor away from other monitors, cordless phones, etc.
- Adjust the brightness using Brightness Control toggle on handheld.
- Test reception by moving the monitor and/or camera to different locations.

Static and squealing sounds:

- Adjust the volume down using the Volume Control on handheld to reduce static.
- Move the camera and monitor further away from each other to eliminate squealing.


SUMMER LINK WIFI APP:

For more information, troubleshooting, and FAQs, visit:

www.summerinfant.com/summerwifi/FAQs

camera setup (table top):

1




Determine a location for the camera that will provide the best view of your baby in the crib. Place the camera on a flat surface, such as a dresser, bureau or shelf. NEVER place camera or cords within **3 feet** of the crib.

2



Be sure to test reception and camera positioning.

3



in-home handheld setup:

Before using the handheld monitor, charge the battery for 12-16 hours. To set up the system, you will need two adults. One adult should view the picture on the monitor while the other is in the nursery to adjust the camera. Often the quality of the reception can be improved by slightly repositioning the camera or the monitor. It may help to place a stuffed animal or doll in the crib to simulate the position and size of your baby.


Step 1: Press and hold POWER/MENU button on handheld monitor unit for 4-seconds until the Summer logo appears on screen. **Video should immediately appear on screen.** If video does not appear, go to "sync the monitor and camera" section (page 7). If video appears, the initial set up test is complete and you can install camera.

camera setup (wall mount option):

⚠️ **WARNING:**

STRANGULATION HAZARD - Children have STRANGLED in cords. Keep this cord out of reach of children (more than 3 feet (0.9 m) away from the crib). Use enclosed Security Clips to help secure cord away from baby's reach. Never use extension cords with AC Adapters. Only use the AC Adapters provided.

Determine a location to mount the camera to the wall that will provide the best view of your baby in the crib. NEVER place camera or cords within **3 feet** of the crib.




Be sure to test reception and camera positioning.

2

IMPORTANT


mount at least 3ft. from crib



Pre-drill a hole in the wall using 3/16", 4.8mm, drill bit. (drill bit and drill not included)


3

Tighten screw until only 1/4" (6.2mm) of the screw is exposed.




(screwdriver not included)

4




5

Secure the cord to the wall using the **6 security clips** included to keep cord away from baby's reach.



6

6



smartphone & tablet features:



Privacy

Privacy Mode allows you to block anyone outside your home from remote viewing. Remote viewers are anyone you've shared access with, viewing on a network other than your home network.



Volume

Press Volume to adjust the volume of your live video. Slider bar will appear. Press mute button to mute all audio. Mute icon will appear in status bar.



Brightness

Press Brightness to adjust the contrast of your video. Slider bar will appear toggle left and right to increase and decrease.



upgrading your APP:

The Summer Link WiFi APP can be upgraded to include the following premium services:

1. Audio Alerts- Choose email or text or push notifications when the noise level reaches your selected settings.
2. Who's Watching Alerts- Choose email or text or push notifications when friends and family are watching.*
3. Receive a Daily Log of alerts received.
4. Someone's Watching Light- the green lights on the camera will switch to white when a guest user begins remotely viewing your camera.*
5. Add access for 3 more friends and family.

Press the Alerts (📢) button at anytime to learn more.

* Privacy mode is always available.



smartphone & tablet features:



Press the up and down arrows and the left and right arrows to move the camera and change view on screen.



Pinch the screen to zoom in on the image on live viewing screen.



Temperature reading from camera will display in the status bar. To switch between Fahrenheit and Celsius enter settings menu.



When someone is viewing remotely this icon will appear in status bar. Remote viewing is anyone you've shared access with, viewing on a network other than your home network.



Snapshot

Press Snapshot to take a picture of your baby at anytime while watching live video. Snapshots will be securely stored on your phone or tablet.



Record

Press Record to record video of your baby at anytime while watching live video. Videos will be securely stored on your phone or tablet.



talk

Press Talk to communicate directly with your baby through your smartphone or tablet.



Splitscreen

Press Splitscreen to view multiple cameras at the same time. This feature requires you to add an additional camera to your system. For more details see "Add a Link WiFi Camera" section.











Settings

Press Settings to manage your account information, add or manage cameras in your system, get help, manage notifications, or find out more information about the APP.








syncing monitor and camera:

The handheld and camera are synced at the factory for privacy reasons. If the monitor and camera are not syncing with each other for any reason, follow steps to re-sync:

1. Move the monitor to the same area as the camera and make sure both are powered on.
2. Press  feature control menu icon.
3. Press  camera menu icon.
4. Press up arrow  to navigate to . Press select icon  to enter the add cam menu.
5. The next available channel will automatically be selected .
6. Press select icon  and syncing animation between the receiver icon and the camera will begin.
7. Within 20-seconds press the code button on the back of the camera. Once synced, live video will appear.



Deleting Camera

1. Press  feature control menu icon.
2. Press  camera menu icon.
3. Press up  arrow to navigate to . Press select  to enter the delete cam menu.
4. Use the up arrow to select the camera you would like to delete.  The camera will highlight orange.
5. Press select to confirm this is the camera you would like to delete. Camera icon will become greyed out and out of range will appear on screen. 

Note: The SCAN, DEL CAM, ADD CAM, and VIEW CAM menu options are only used with additional cameras. (See page 13 for more info on adding cameras to the system.)

in-home handheld monitor features:

- **Temperature Monitoring:** Monitoring the temperature in baby's room is easy with the option to display it on screen and helps parents know baby is comfortable. The temperature reading can be switched from Fahrenheit to Celsius by pressing the temperature button once. To turn display off, press button twice.
- **Video On-Off Button:** This button turns the video on and off. Audio and sound lights continue to function normally. It is ideal for a quick view of baby in the middle of the night. To monitor in audio only mode, simply press the Video On/Off button to turn the video screen off.
- **Power Save Mode:** While operating the handheld unit on battery power, the video screen will go to sleep, to conserve battery power. Audio and sound lights continue to function normally. With one-touch of the Video On/Off button, video resumes on screen.


- **Adjustable Volume & Brightness:** Volume adjustments allow higher volume settings to hear every little sound while lower volume settings monitor the louder sounds from baby. Easily increase and decrease the brightness on your monitor screen by pressing the up and down arrows in the feature control menu to accommodate to the level of light in the room.
- **Sound Lights:** The video monitor lets you not only hear your baby but with sound lights parents can “see” when sound is coming from baby’s room. Displayed on a color bar above the video screen, the color changes from green to amber to red as the sound level increases. These lights can be especially helpful for parents when they are in crowded or noisy rooms.

camera features:

- **Pan/Scan:** Keeping baby in view is important as they get more mobile and curious. Parents can use the pan and scan feature to adjust the camera view up and down or left and right to keep baby in view at all times.
- **Motion Tracking:** Allows you to activate the camera for automatic movement detection and it follows any movement by baby. The camera refocuses after movement stops.
- **Multi-Level Zoom:** Multi-level zoom enables increasing levels of a zoomed-in image on screen. This provides parents with much closer views on screen than one-level zoom, with the option to view from 1 to 3 times closer.
- **Talk-Back/Two-Way Communication:** Calm baby with the sound of your voice with talk-back. Parents speak into the handheld unit or their smart device and their voice is projected through the camera. It’s reassuring for parents to be able to talk to or soothe a crying baby. It’s also a convenient tool for parents, making communication easy if one of them needs a reminder to bring something from one room to another.
- **Night Vision:** Rest assured knowing you can see your baby day and night with automatic night vision. The system automatically adjusts to the level of light in the room to keep your baby in view in low light and dark room conditions, making it easy to continue monitoring overnight. Night vision video is displayed in black and white.
- **Internet Status Lights:** The lights on the front of the camera will tell you the status of your camera’s connection to an internet source (see page 9 for more details).

internet status lights:

1




Remote Internet & Local Internet Connection

Four solid green LEDs indicates your camera has a local and remote internet connection. This means you can view on your smartphone, tablet, or computer in and out of your home.



Note: You can turn off the lights on the front of the camera by sliding the Internet Status Light switch on back of camera.

2




Local Internet Connection Only

Two green LEDs (north and south position) and two white LEDs (east and west position) indicates a local internet connection. This means that you can view on your smartphone, tablet, or computer in your home but you will not be able to view out of your home. You will need to re-configure your camera’s connection to resolve this issue.



Visit www.summerinfant.com/summerwifi/FAQs to help troubleshoot.

3



Someone’s Watching Light

When all of the green LEDs on the front of your camera switch from green to white, this means that a user you have given access to has logged in and begun watching your camera over a remote internet connection. The LEDs will change back to green when they have stopped watching.



Requires app upgrade package, see “upgrading your app” section.