

Waterproof Bluetooth Speaker

Model: BW-201

Instruction Manual



1. Introduction

Thank you for using our Waterproof Bluetooth Speaker.


- This speaker is one of our portable Bluetooth Speakers.
- This product is a high-quality speaker, and it has high practical value, so it receives lots of clients' favors.

2. Specification

Bluetooth version	Bluetooth 3.0
Operating frequency	2.402~2.480GHz
Dimension	206*47*155.5mm
Output Power (Total)	3W*2
Speaker Driver Unit	2 inch*2
Sensitivity	550mv/1KHZ
Power Supply	① DC 3.7V/1500mAh Rechargeable lithium battery
	② DC 5V by Micro USB
Waterproof Grade	IPX6

3. Operating instructions

● Function Description



- | | |
|---|--|
| ①  Volume - | ②  Volume + |
| ③  Answer/ Hang up the phone; Redial the last number | |
| ④  Pair with the phone; ON/OFF | ⑤  Play/Pause |
| ⑥  Previous song | ⑦  Next song |

● Method of attachment

- ① Turn ON/OFF on.
- ② Press and hold the key “” for a few seconds, until the Indicator LED flashes red and blue alternately.
- ③ Turn on the phone. Follow these steps to activate the phone's Bluetooth Function.
 - a) Open the Settings menu
 - b) Select the General menu> Bluetooth
 - c) Set the Bluetooth to open

Immediately, the phone begins to search the surrounding Bluetooth devices, and the Bluetooth devices found will be listed. The speaker will be named : “PBT600” in the list of the Bluetooth devices, the state is no pairing, no connection.
- ④ Open the mating connector, the phone display prompts that the speaker is connected, the back of the speaker's Indicator LED starts flashing blue light. You can start music player, for example, the related functions in the phone can be transmitted to the speaker.
 - a) You might be asked to enter a password, if prompted, enter 1234.
 - b) Always follow the guidelines of the operation by your phone.

● Bluetooth playing mode

- ① If a song has been played a short time, press the key “” once to play the previous song.
- ② If a song has been played a long time, press the key “” once to play the playing song from beginning.
- ③ Press the key “” once to play the next song.
- ④ Press the keys “” and “” to control the volume.
- ⑤ In the Bluetooth playing mode, open the music player in your phone, then press the key “” once to play or pause the music.

- ⑥ If someone telephone in, this speaker will inform the number of coming call in English. Press the key “” once to answer the call, and press the key “” once again to hang up the call.
- ⑦ Press and hold the key “” for a few seconds to prepare for another connection. Or hold the key “” for longer time to shut down the Bluetooth.

Charging for the power

1. There is a rechargeable lithium battery in this speaker.
2. Charging supply: Computer USB port or DC 5V.
3. To prolong the battery service life, please charge it above 4 hours when it was used up first time. After the first time, charge it about 2-3 hours will be enough.
4. When it is charging, the Indicator LED light red while the battery is not saturated, and the LED turn green while the battery is saturated

Precautions

- For your safety, please read the description and accordance the instructions to use this product.
- Insure that properly to use this product, and avoid the damages or strong impacts to this product.
- Do not disassemble, repair or modify this product by yourself.
If the battery is replaced by an incorrect type, it is a risk of explosion.
- This product can not be boiled or exposed to the sun, and use it at the room temperature.
- This product is not a toy, keep away from the children.
- This product contains the recyclable lithium battery, sent it to the specialty Recycle Bin for recycling please.

FCC Statement:

This equipment has been tested and found to comply with the limits for Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: Modifications to this product will void the user's authority to operate this equipment.