





External antenna connection position

- (3 places)
- EXT-ANT1
- EXT-ANT2
- EXT-ANT3



Label



External antenna

Controller