

## PULSE 2

## BLUESOUND®



© Bluesound International. Bluesound, the stylized wordmark and "B" logotype, the phrase "HiFi for a wireless generation", PULSE 2 and all other Bluesound product names and taglines are trademarks or registered trademarks of Bluesound International, a division of Lenbrook Industries Limited. All other logos and services are trademarks or service marks of their respective owners.

Quick Setup Guide bluesound.com

## Included Accessories



120V AC Power Cord



230V AC Power Cord



Ethernet Cable



Mini Jack to Toslink Adaptor

## PULSE 2 All-in-one Wireless Streaming Music System

English	
Français	8
Español	g
Italiano	10
Português	1
Deutsch	12
Nederlands	13
Svenska	14
Русский	15








### CONNECT ZO POWER



- A Select the AC Power Cord appropriate for your region and plug it into the Player, and then into your wall outlet.
- B The PULSE 2's LED button should turn Solid Green, indicating that the player is in Hotspot Mode and ready to be added to your home WiFi network.

Never force a power cord into a wall outlet. An adaptor may be necessary in certain regions.





To see an instructional video on WiFi Setup, please visit

### **CONNECT TO WIFI**

- A On your tablet or smartphone, look for the WiFi network (hotspot) matching your PULSE 2's unique network ID, and join it. The network ID is listed as the product name (i.e. PULSE 2) immediately followed by the last four digits in the MAC (Machine Access Control) address (example: PULSE2-001A). The full 12-digit MAC address is printed on a sticker on the back panel of your Player.
- B Open a web browser on your tablet or smartphone and enter **setup.bluesound.com**, and press "Go". A control panel page should then appear.
- C From the main menu displayed, select Configure WiFi.
- D Select your home WiFi Network from the Configure Wireless drop down menu.
- E Enter your home network's Wireless Password in the field provided (if it is a protected network).
- F Select a **Room Name** from the drop down list, or create a customized Room name in the field provided.
- G Press **Update** and wait for the Player's light to turn solid blue, indicating that the Player has successfully joined your home WiFi network.
- H Repeat steps A-G for each additional Bluesound Plauer.
- I Reselect your home WiFi network from your tablet or smartphone's main network settings.

Alternatively, the PULSE 2 can be connected directly to your wired home network or router using the Ethernet cable provided.









# 3

### DOWNLOAD THE APP

All Bluesound Controller Apps for Apple iOS devices (iPhone, iPad, iPod), Android devices, Kindle Fire, and Windows or Mac desktops are available for download at www.bluesound.com/downloads

### Congratulations, your Player setup is complete!

It's time to connect your music. Launch the App for the following playback options.







4



### **CONNECT TO MUSIC**

Your Music: To play music stored on a computer or NAS device, open the Navigation Drawer by tapping: in the App, choose Configure Player from the menu, and select Configure Network Shares. Follow the screen prompts, and open every Room in your home to your entire digital music library.

Internet Radio: Simply select TuneIn from the Music Services menu, and find your favorite radio station. Or, explore and discover the thousands of radio stations streaming live 24/7 from anywhere on the planet via TuneIn.

For detailed information, please visit www.bluesound.com











