






LS800 Antenna Locations




LS800 Aux antenna location



LS800 BT Module location




VSWR of Main Antenna (White cable, Left antenna)



VSWR of Aux Antenna (Black cable, Right antenna)



DB1 Markers
#1 1.2532
2.40000 GHz
#2 1.1251
2.50000 GHz
#3 1.2016
5.25000 GHz
#4 2.0174
5.67500 GHz



Spec:
VSWR < 2.0 @ 2.4 ~ 2.5 GHz
VSWR < 2.5 @ 5.15 ~ 5.875 GHz