




按鈕功能



產品規格

1. 產品型號：RC-A01
2. 外型尺寸：長135mm x 寬50mm x 高9.3mm
3. 重量(含電池)：62g ± 5g
4. 電池規格：CR2032 3V (一次性鋰電池)
5. 發射頻率：2.4GHz
6. 操作溫度：0°C - 50°C / 32°F - 122°F


NCC 警語

- 取得審驗證明之低功率射頻器材，非經核准，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。
- 低功率射頻器材之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前述合法通信，指依電信管理法規定作業之無線電通信。低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。


更換電池說明

此遙控器使用2顆鈕扣電池CR2032，出貨時已內含電池，首次使用請先移除絕緣片


遙控器背面




1. 用螺絲起子取下電池蓋螺絲



2. 向下推開電池蓋



3. 電池正極(+)朝上以傾斜角度放入電池槽



4. 裝回電池蓋

⚠️ 警告：請妥善保管新舊電池，使其遠離六歲以下嬰幼兒，避免誤吞造成危險

遙控器與窗簾配對


以電動蜂巢簾為例，其他窗簾類型請參照各產品說明書

⚠️ 重要！同一個群組內請配對相同的窗簾類型，以達最佳操作體驗。



1. 窗簾按鈕連按3下

窗簾綠燈慢閃，進入配對模式



2. 遙控器背面SET長按3秒

燈慢閃，進入SET模式




3. 選擇欲配對的群組

被選擇的數字閃爍



窗簾抖動提示
配對成功 抖動1次



4. 遙控器背面SET長按3秒

燈停閃，離開SET模式

ⓘ SET模式下20秒無操作，也將自動離開SET模式

解除配對

將已配對群組的窗簾，執行左側步驟並重複配對在同一群組，則解除配對

窗簾抖動提示
解配成功 抖動2次




更改群組配對

請先按照上述步驟將該窗簾自原本群組解除配對，接著再次執行左側配對步驟，並在步驟3選擇欲更改的新群組



Button Functions



Product Specification

FCC ID: Q3V-RC-A01
IC: 28542-RCA01

1. Model : RC-A01
2. Dimensions : L 135mm x W 50mm x H 9.3mm
3. Weight (including battery) : 62g ± 5g
4. Battery / Voltage : CR2032 3V (Lithium coin battery)
5. Radio Frequency : 2.4GHz
6. Operation Temperature : 0°C - 50°C / 32°F - 122°F


CE Information

Hereby, Nien Made Enterprise Co., Ltd. declares that this RC-A01 is in compliance with the essential requirements and other relevant provisions of Radio Equipment Regulations 2017.

Battery Replacement

The 5-group remote control comes with 2 CR2032 batteries included. Please remove the protective film before use.

Back of the remote




CAUTION : Please keep the batteries out of the reach of children 6 years old and under.


Assigning Shades to Remote Group

The example shown below is for cellular honeycomb shades. For other products, please refer to the specific user manual.

IMPOTANT! Please assign only one type of shades in the same group for optimal operation.




1. Press shade button 3 times.
The green light will start flashing while shade is in Pairing mode.



2. Hold SET button for 3 seconds
The remote will enter the Setup mode and the group light will start blinking.



3. Choose a desired group
The selected group number blinks.



4. Hold SET button for 3 seconds
The remote will leave the Setup mode and the group light will stop blinking.

i Setting mode will time out after 20 seconds of inactivity.

Removing Group assignments

Repeat the steps under Assigning Shade and assign to the same group again to remove from the group.



Changing Group assignments

Follow the step above to remove the original shade assignment first. Next, repeat the steps under Assigning Shades and choose a different Shade Group number in step 3.



FCC Information

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION:

Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.

IC Information

Innovation, Science and Economic Development Canada (ISED) Notices

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

Canada, avis d'Industry Canada (ISED)

Cet appareil contient un ou des émetteurs/récepteurs exempts de licence conformes aux RSS exempts de licence d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:

1. Cet appareil ne doit pas causer d'interférences.
2. Cet appareil doit accepter toutes les interférences, y compris les interférences pouvant entraîner un fonctionnement indésirable de l'appareil.

CAN ICES-003(B) / NMB-003(B)

RF Exposure Warning

The equipment complies with FCC/ISED RF exposure limits set forth for an uncontrolled environment.

The equipment must not be co-located or operating in conjunction with any other antenna or transmitter.