



FORWARD
BACKWARD

PULL
FUNCTIONS
SWITCH



FORWARD
BACKWARD
LEFT
RIGHT



FORWARD
LEFT
RIGHT

FORWARD
LEFT
RIGHT
STOP



7 FUNCTIONS :

- FORWARD
- BACKWARD
- FORWARD LEFT
- BACKWARD LEFT
- FORWARD RIGHT
- BACKWARD RIGHT
- STOP

7 FUNCTIONS :

- FORWARD
- FORWARD LEFT
- FORWARD RIGHT
- STOP
- BACKWARD
- BACKWARD LEFT
- BACKWARD RIGHT

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



INSTALL BATTERIES AS SHOWN

