



A-D/I/O E-SDA		
TONE1	H-D0	BUSY
RESET	H-D1	VOX
PLL-UL	H-D2	QT/DQT IN
W-BUSY	H-D3	MANDOWN
A-TCLK	H-DV	
A-RDT	BATT	
C-RXD1	RSSI	
VCCN	VOX SW	W-SCLK
TONE0	MIC MUTE	W-MUTE
E-SCL	TX SW	LAMP
SHIFT	PLL-STB	HPC PC
E-TEST	PLL-DATA	
A-SCLK	PLL-CLK	
A-TDATA	MAX AF SW	
A-DIR	GREEN	
QTVCO	RED	
PLL-LP	5TC	
PC/TV	5RC	
QT TCXO	5CC	
C-TXD1	W/N N	
PABC	W/N W	
APC2 SW	AFCO	
APC1 SW	RX MUTE	
RX SW	W-DATA	

PTT BOARD		
PTT	PF1	PF2
SW		
PF3		

KEY BOARD		
KEY		
1	2	3
4	5	6
7	8	9
*	0	#

Title		
Size	Number	Revision
A3		
Date:	2007-10-10	Sheet of
File:	F:\PT6500\PT6500 BLOCK DEAGRAPH	Dr:Schl