

## PT6500-02 Adjustment Procedure

### 1. Frequency Adjust

a. setup the equipment as follow.

Setup:




b. let the PT6500-02 working in high frequency channel (468.200MHz).

c. adjust the VR1. let the frequency deviation is lower than 100Hz.

### 2. High power Adjust

a. setup the equipment as follow.

Setup:



b. running Software:KSP7200, set the power to 4.0W

c. adjust the software, let the power deviation is lower than 0.2W.