

# Self-learning type of Wireless Remote Control Socket Instruction Manual

## Model no.: BH9938U

Please read the Instructions carefully before using the product.

### **Product:**

This Remote Control Socket consists of one transmitter (FCC ID : Q92BHOP) and several socket receivers (FCC ID : Q92-BH9938U)

### **Installation:**

Install one (1) x 12V (23A) battery in the compartment of Remote Control. , make sure the installation of battery is correct.

### **Features:**

- ◆ The Outlets can be manually operated or via the handy Remote Control.
- ◆ Individual ON & OFF function for the remote control.
- ◆ Easy to use and operate. Use one transmitter to match more socket receivers or program more than one transmitter to each socket. Any one transmitter and socket receiver can match use after finish programming operation. So the socket receiver and remote control can sell separately.
- ◆ The socket receiver will still remain in the "OFF" mode after a power out, even when the power comes on again.

### **Technical data:**

Working Voltage for socket.....100V-127V~/60Hz  
Receiver frequency..... 433.92MHz  
Max.load current..... 10A  
Power for Remote Control..... DC12V 23A battery

### **Detailed Learning Operation:**

All remote controlled socket units have been pre-programmed and can be used immediately.

To re-program the remote control transmitter and socket receiver, please follow instructions below.

- Plug the remote controlled socket to a power point and turn the power on.
- Press and hold the learning button on the right and side of the socket receiver for about 5 seconds till the LED indicator flashes.
- Release the learning button and press the preferred " on" or "off" number button of the transmitter.
- Programming successful when the LED indicator stops flashing.
- The remote controlled socket is now ready to use.
- Remote set up only requires one-time programming.

### **Change the battery:**

Regularly change the battery in the remote control for best use – however if you find the receivers are not responding or the LED indicator of remote control becomes dim, then you must change the battery at the earliest available time. Always dispose of old batteries with consideration for the environment.

### **NOTES:**

- Make sure the battery and socket installation is firm, safe and correct.
- For indoor use only, it should be installed in the places of aeration and far from high-temperature source. Make sure to avoid strong sunlight, raining and moisture places
- Do not exceed the maximum load current.

### **FCC Warning:**

- Changes or modifications to this unit not expressly approved by the party responsible for compliance will void the user's authority to operate the equipment. Any change to the equipment will void FCC grant.
- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.