


Getting Started | Erste Schritte | Démarrage | Iniziared



Media | Medium | Media | Elementi multimediali


Mobile | Intercom | Handy | Gegensprechanlage | Téléphone | Interphone | Telefono | Interfono

Volume Up | Lautstärke erhöhen | Augmenter volume | Alza il volume


Volume Down | Lautstärke verringern | Baisser volume | Abbassa il volume

Getting Started | Erste Schritte | Démarrage | Iniziared

On / Off | Ein / Aus | On / Off | Acceso/Spento




Phone Pairing | Telefon-Kopplung | Appairage au téléphone | Abbinamento telefono




General | Allgemein | Fonctions générales | Generale



Volume Up | Lautstärke erhöhen | Augmenter volume | Alza il volume



Volume Down | Lautstärke verringern | Baisser volume | Abbassa il volume



Mute | Stummschalten | Mute | Silenzia




Cardo Connect App


Download | Download | Télécharger | Scarica



Register | Registrieren | S'inscrire | Registrati




Update



Phone Call | Telefongespräch | PAppel téléphonique | Telefonata

Answer | Antworten | Répondre | Rispondi



Ignore | Ignorieren | Ignorer | Ignora



End Call | Anruf beenden | Raccrocher | Termina chiamata





Redial | Wahl wiederholen | Fonction bis | Ricomponi



Speed Dial

Speed Dial




Call Speed Dial | Kurzwahl anwählen | Appel numérotation rapide | Chiama composizione veloce




Radio | Radio | Radio | Radio


Set Presets | Voreinstellungen festlegen | Définir les préréglages | Imposta stazioni




Start Scan | Suchlauf starten | Commencer la recherche | Inizia scansione



Stop Scan | Suchlauf beenden | SArrêter la recherche | Interrompi scansione




On | Ein | On | Acceso



Off | Aus | Off | Spento



Next | Weiter | Suivant | Successiva



Previous | Zurück | Précédent | Precedente

