



802.11ax-HE20

Channel 93 (6415MHz)

The Reference Level




The Mask Data




Channel 97 (6435MHz)

The Reference Level




The Mask Data




Channel 105 (6475MHz)

The Reference Level




The Mask Data




802.11ax-HE20

Channel 113 (6515MHz)

The Reference Level




The Mask Data




Channel 117 (6535MHz)

The Reference Level




The Mask Data




Channel 157 (6715MHz)

The Reference Level



The Mask Data





802.11ax-HE20

Channel 181 (6855MHz)

The Reference Level



The Mask Data



Channel 185 (6875MHz)

The Reference Level



The Mask Data



Channel 189 (6895MHz)

The Reference Level


The Mask Data




802.11ax-HE20

Channel 213 (7015MHz)

The Reference Level




The Mask Data




Channel 229 (7095MHz)

The Reference Level




The Mask Data




802.11ax-HE40

Channel 03 (5965MHz)

The Reference Level




The Mask Data




Channel 51 (6205MHz)

The Reference Level




The Mask Data




Channel 91 (6405MHz)

The Reference Level




The Mask Data




802.11ax-HE40

Channel 99 (6445MHz)

The Reference Level




The Mask Data




Channel 107 (6485MHz)

The Reference Level




The Mask Data




Channel 115 (6525MHz)

The Reference Level




The Mask Data




802.11ax-HE40

Channel 123 (6565MHz)

The Reference Level




The Mask Data




Channel 147 (6685MHz)

The Reference Level




The Mask Data




Channel 179 (6845MHz)

The Reference Level




The Mask Data




802.11ax-HE40

Channel 187 (6885MHz)

The Reference Level




The Mask Data




Channel 195 (6925MHz)

The Reference Level




The Mask Data





Channel 211 (7005MHz)

The Reference Level



The Mask Data







802.11ax-HE80

Channel 07 (5985MHz)

The Reference Level




The Mask Data




Channel 55 (6225MHz)

The Reference Level




The Mask Data




Channel 87 (6385MHz)


The Reference Level




The Mask Data



802.11ax-HE80
Channel 103 (6465MHz)



Channel 119 (6545MHz)



Channel 135 (6625MHz)

