



802.11ax-HE40

Channel 227 (7085MHz)

The Reference Level




The Mask Data



802.11ax-HE80

Channel 39 (6145MHz)

The Reference Level




The Mask Data




Channel 55 (6225MHz)

The Reference Level




The Mask Data




Channel 87 (6385MHz)

The Reference Level




The Mask Data




802.11ax-HE80

Channel 103 (6465MHz)

The Reference Level




The Mask Data




Channel 119 (6545MHz)

The Reference Level




The Mask Data




Channel 135 (6625MHz)

The Reference Level




The Mask Data




802.11ax-HE80

Channel 151 (6705MHz)

The Reference Level




The Mask Data




Channel 167 (6785MHz)

The Reference Level




The Mask Data




Channel 183 (6865MHz)

The Reference Level




The Mask Data




802.11ax-HE80

Channel 199 (6945MHz)

The Reference Level




The Mask Data




Channel 215 (7025MHz)

The Reference Level




The Mask Data




802.11ax-HE160

Channel 47 (6185MHz)

The Reference Level




The Mask Data




Channel 79 (6345MHz)

The Reference Level




The Mask Data




Channel 111 (6505MHz)

The Reference Level




The Mask Data




802.11ax-HE160

Channel 143 (6665MHz)

The Reference Level




The Mask Data




Channel 175 (6825MHz)

The Reference Level




The Mask Data




Channel 207 (6985MHz)

The Reference Level




The Mask Data




802.11be-EHT20

Channel 33 (6115MHz)

The Reference Level




The Mask Data




Channel 61 (6255MHz)

The Reference Level




The Mask Data




Channel 93 (6415MHz)

The Reference Level



The Mask Data







802.11be-EHT20

Channel 97 (6435MHz)

The Reference Level




The Mask Data




Channel 105 (6475MHz)

The Reference Level




The Mask Data




Channel 113 (6515MHz)

The Reference Level




The Mask Data




802.11be-EHT20

Channel 117 (6535MHz)

The Reference Level




The Mask Data




Channel 149 (6695MHz)

The Reference Level




The Mask Data




Channel 181 (6855MHz)

The Reference Level




The Mask Data




802.11be-EHT20

Channel 185 (6875MHz)

The Reference Level




The Mask Data




Channel 189 (6895MHz)

The Reference Level




The Mask Data




Channel 209 (6995MHz)

The Reference Level




The Mask Data




802.11be-EHT20

Channel 229 (7095MHz)

The Reference Level




The Mask Data




802.11be-EHT40

Channel 35 (6125MHz)

The Reference Level




The Mask Data




Channel 59 (6245MHz)

The Reference Level




The Mask Data




Channel 91 (6405MHz)

The Reference Level




The Mask Data




802.11be-EHT40

Channel 99 (6445MHz)

The Reference Level




The Mask Data




Channel 107 (6485MHz)

The Reference Level




The Mask Data



Channel 115 (6525MHz)

The Reference Level



The Mask Data

