



802.11ax-HE20 - Ant 0

Channel 209 (6995MHz)

The Reference Level




The Mask Data




Channel 229 (7095MHz)

The Reference Level




The Mask Data




802.11ax-HE40 - Ant 0

Channel 3 (5965MHz)

The Reference Level




The Mask Data




Channel 51 (6205MHz)

The Reference Level




The Mask Data




Channel 91 (6405MHz)

The Reference Level




The Mask Data




## 802.11ax-HE40 - Ant 0

## Channel 99 (6445MHz)

## The Reference Level




## The Mask Data




## Channel 107 (6485MHz)

## The Reference Level




## The Mask Data




## Channel 115 (6525MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE40 - Ant 0

## Channel 123 (6565MHz)

## The Reference Level




## The Mask Data




## Channel 147 (6685MHz)

## The Reference Level




## The Mask Data




## Channel 179 (6845MHz)

## The Reference Level




## The Mask Data




802.11ax-HE40 - Ant 0

Channel 187 (6885MHz)

The Reference Level




The Mask Data




Channel 195 (6925MHz)

The Reference Level




The Mask Data





Channel 211 (7005MHz)

The Reference Level



The Mask Data







802.11ax-HE80 - Ant 0

Channel 7 (5985MHz)

The Reference Level




The Mask Data




Channel 55 (6225MHz)

The Reference Level




The Mask Data




Channel 87 (6385MHz)

The Reference Level




The Mask Data




802.11ax-HE80 - Ant 0

Channel 103 (6465MHz)

The Reference Level




The Mask Data




Channel 119 (6545MHz)

The Reference Level




The Mask Data




Channel 135 (6625MHz)

The Reference Level



The Mask Data







## 802.11ax-HE80 - Ant 0

## Channel 151 (6705MHz)

## The Reference Level




## The Mask Data




## Channel 167 (6785MHz)

## The Reference Level




## The Mask Data




## Channel 183 (6865MHz)

## The Reference Level




## The Mask Data




802.11ax-HE80 - Ant 0

Channel 199 (6945MHz)

The Reference Level




The Mask Data




Channel 215 (7025MHz)

The Reference Level




The Mask Data




802.11ax-HE160 - Ant 0

Channel 15 (6025MHz)

The Reference Level



The Mask Data




Channel 47 (6185MHz)

The Reference Level




The Mask Data




Channel 79 (6345MHz)

The Reference Level




The Mask Data




## 802.11ax-HE160 - Ant 0

## Channel 111 (6505MHz)

## The Reference Level




## The Mask Data




## Channel 143 (6665MHz)

## The Reference Level




## The Mask Data




## Channel 175 (6825MHz)

## The Reference Level



## The Mask Data



802.11ax-HE160 - Ant 0

Channel 207 (6985MHz)

The Reference Level

The Mask Data

