


Instructions

Thanks for purchasing your new Nakamichi Junkyard Smash, Please read the following instructions carefully before operation.

This set includes the following items:

- (1) Blue Vehicle – frequency 27MHz
- (2) Red Vehicle – frequency 49MHz
- (3) Transmitter – frequency 27MHz
- (4) Transmitter – frequency 49MHz

Batteries are sold separately. See Battery Installation for details.



FCC Compliant

This device complies with part 15 of the FCC rules. Operation is subject to the condition that this device does not cause harmful interference.

FCC ID: QCT234508904
FCC ID: QCT234508905

Transmitter

The Transmitter is used to control the Nakamichi vehicle. You can turn it on with the Power Switch located on the front of the transmitter.

Note: Make sure the Transmitter has same frequency as on vehicle.

Power Switch:

When not in use, be sure to turn the switch to the "OFF" position to conserve battery power.

Removable battery box:

The removable battery box is used to provide power supply to the transmitter.

Sound of Horn Button:

Press button for sound of engine, and horn.

Using your Nakamichi Vehicle

To use, turn the switch on the Transmitter to "ON". Then turn vehicle power on using switch on bottom of the vehicle. When not in use, be sure to turn power off to conserve batteries.

Steering alignment – If your vehicle does not drive straight, use the alignment trim to adjust the steering.

The Nakamichi vehicle has sensors on rear bumper and side doors, it will pop-over while crashing by other vehicle.

Note: Do not pick up the vehicle by holding the side doors and rear bumper, it may damage the sensors.

Safety and Playing Tips

Vehicles are designed to run only on smooth, clean surfaces.

When driving, avoid long pile carpet, pet hair, and dirty surfaces.

Never drive your Vehicles on streets.

Do not play outdoors during thunderstorms.

Do not drive your Vehicle in sand or through water or snow.

Be careful not to drive out of transmitter frequency range. You may lose control of your vehicle.

Wipe clean with a dry towel after play. Do not use chemicals or detergents as they can damage the body.

Do not store vehicles or transmitter in direct sunlight.

Keep fingers, hair, and loose clothing away from the spinning wheels.

Operation of multiple vehicles in close proximity may cause interference or poor performance.

High voltage power lines may cause radio interference.

If your Vehicle appears to lose range or power, try replacing batteries in Transmitter or Vehicle.

Battery Installation

Your Nakamichi Transmitters and Vehicles requires a total 12 x AA batteries (not included)

3 x AA type alkaline batteries are required for each Vehicle (total 6 batteries)

3 x AA type alkaline batteries are required for each Transmitter (total 6 batteries)

You will need a small screwdriver (not included) to access batteries.

When replacing batteries, be sure to align "+" and "-" correctly.

Battery Warning

Batteries should be replaced under adult supervision.

For best performance, use only alkaline batteries.

Dispose of batteries safely and correctly.



Do not dispose of old batteries in fire. Batteries may leak or explode.

Do not use rechargeable batteries.

Do not mix old and new batteries.

Do not mix alkaline batteries with either standard (carbon zinc) or rechargeable (Nickel cadmium) batteries.

Exhausted batteries should be removed from the toy.



Please keep instructions for future reference.

#20592

FULL FUNCTION R/C JUNKYARD SMASH INSTRUCTION MANUAL

USER MANUAL INSERTS FOR PART 15

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Senario™

www.senario.com
2003 Senario LLC
McHenry, IL 60050
PHONE 815-385-2438
FAX 815-425-0028
All Rights Reserved

Tested to Comply
with FCC Standards
for HOME OR
OFFICE USE

Printed in China

NAKAMICHI 



(Actual Products may vary from images shown)

Instruction Manual

Senario™

Recommended for ages 8 and up
© 2003 Senario LLC, McHenry IL USA
All Rights Reserved
Made in China



WARNING:
CHOKING HAZARD - Small Parts
Not for children under 3 years