


# AK120 QUICK START GUIDE

ENGLISH

## Names of parts




## Turn on/off

1. Press and hold the [⏻] key to turn on.
2. When stand by, Press and hold the [⏻] key to turn off.

## Connecting to a computer

1. Turn on the product and computer, and use the Micro USB cable to connect the product to a computer.



## Charging

1. The built-in battery will charge automatically when connected to computer.

## Installing iriver plus 4

1. Run the iriver plus 4 installation program stored on the internal memory, the program installation instruction dialog will be displayed.
2. Follow the instructions to install the program.

## Listening to music


1. Select Music Search Method from the home screen to display the music list.
2. Select the song you desire to play from the list.

The user manual is stored in the device as a PDF file.  
(You can also download the user manual from [iriver.com](http://iriver.com).)

# AK120 QUICK START GUIDE

KOREAN

## 각 부의 명칭




## 전원 켜기/끄기

1. 제품의 [⏻]키를 길게 누르면 전원이 켜집니다.
2. 제품이 켜진상태에서 제품의 [⏻]키를 길게 누르면 전원이 꺼집니다.

## 컴퓨터와 연결하기

1. 제품과 컴퓨터의 전원을 켜 후, 제공된 Micro USB 케이블을 이용하여 제품과 컴퓨터를 연결합니다.



## 충전하기

1. 컴퓨터와 연결하면 자동으로 내장 배터리가 충전됩니다.

## iriver plus 4 설치하기

1. 제품의 내장 메모리에 저장되어 있는 iriver plus 4 설치 프로그램을 실행하면 프로그램 설치 안내화면이 나타납니다.
2. 프로그램의 안내에 따라 설치를 완료합니다.

## 음악 듣기

1. 홈 화면에서 음악 검색 방식을 선택하면 음악목록이 표시됩니다.
2. 음악목록에서 재생할 음악을 누르면 음악이 재생됩니다.

사용자 설명서는 PDF파일로 제품에 저장되어 있습니다. (사용자 설명서는 [iriver.co.kr](http://iriver.co.kr)에서 다운 받을 수 있습니다.)