

# 1. Product Description

WorldPenScan Go is a portable scanning translation pen that is easy to carry.

This is an intelligent product that integrates scanning, OCR (text recognition), search, sentence translation, voice translation and reading aloud technologies.



Use it to scan the text of the book to look up words and learn; after connecting to the Internet, it allows you to chat between Chinese and English conversations.

## © Package Contents

- Pen scanner x1
- Type-C USB cable x1
- Quick guide and warranty card x1

## © Product Specifications

- Product Name: WorldPenScan Go
- Screen: 2.98 inches (resolution 800\*268)
- Storage size: 8G
- Lens: 300 mega pixels
- Use environment: 0° C-45° C
- Product size: 146.59\*34\*13.87mm
- Speaker: 8 ohm 1 watt single speaker
- Transmission and charging cable: Type-C
- Battery: 1050mAh rechargeable polymer battery



## 2. Function Introduction

### ⊙ Power On/Off

Long press the 【On/Off】 button for about 3 seconds.

### ⊙ WIFI Connection

Go to 【Settings】 and turn the 【WiFi switch】 ON, then choose a usable WIFI to connect.

After connecting successfully, there will be the WIFI icon at the top right corner.

When using this product outdoors, you can choose to use the mobile hotspot for WiFi connection.


### ⊙ Dictionary Lookup


Tap the 【Dictionary Lookup】 icon to enter and scan a text on the book.

Hold the pen, aim the alignment line on the pen tip to the middle of the text, gently press down the pen tip to let the light bright up, then drag the pen to the right at a steady and constant speed, and lift the pen at the end of the text to finish scanning.

Caution:

· Please tilt the pen tip slightly to let it touches the paper surface.





After scanning, tap a word to check the dictionary contents.

Swipe from the right side of the screen to the left to pull out the menu to enter advanced settings.

Tap **【Speaker】** icon to speak out, tap **【Star】** icon to add it into favorite.

## ◎ **Live Translation**

After connecting to the WIFI network, tap **【Live Translation】** icon to enter this feature.

Set the languages you are going to use, then press and hold the A or B button corresponding to your languages and start speaking. After you release the button, you can directly translate into the other language and read it aloud.

## ◎ **Instant Translation**

Tap **【Instant Translation】** icon to enter and scan sentences on the book, then the translations will show up.

Tap the sentences to speak out, and swipe from the right side of the screen to the left to pull out the menu to enter advanced settings.

## ◎ **Text Capture**

Tap 【Text Capture】 icon to enter.

Create a file then you can start to scan the document.

After scanning, you can edit the file name or delete the file.

## ◎ **Recorder**


Tap 【Recorder】 icon to enter.

Create a file then you can start to record the voices.

## ◎ **USB Charging**

When the system prompts that the battery is low, please charge it in time.

It takes 2-3 hours to charge the pen.



Please use the specific USB Type-C cable with the DC5V---1A-3A adaptor to charge.

## ◎ **Connect to Computer**

Please use the specific USB Type-C cable to connect with your computer.

You can access the files after the volume of the pen appears on the computer.



PenPower

# Warranty Card

Thank you for purchasing PenPower product.

Please register your product on [www.penpower.net/reg.htm](http://www.penpower.net/reg.htm) to ensure warranty service:

- 1 Year Warranty
- Software Updates
- Technical Support

Note:

- The warranty period begins on the purchase date, standard warranty period ends 12 months after the purchase date.
- Product warranty is limited to the origin of purchase. Users might pay a service fee when requesting warranty service in different country.
- A copy of the official invoice must be submitted as proof of purchase for warranty service.



PenPower

# Warranty Card

Product Name: \_\_\_\_\_

Purchase Date: \_\_\_\_\_

Dealers Signature

## PenPower Technology Ltd.

Global Operations:

USA +1-510-897-6600

Taiwan +886-2-2778-1922

Hong Kong +852-2111-1548

Guangzhou +86-20-8776-2205

[www.penpower.net](http://www.penpower.net)

### Remarks:

If you are not using the specific USB Type-C cable, you may not be able access the files but only can charge the pen.

## ⦿ Volume Adjustment

Press 【Volume+】 / 【Volume -】 buttons to adjust the volume.

## ⦿ System Reset

Long press the 【On/Off】 button for at least 10 secs, the system will reset and reboot.

## ⦿ Software Update

Tap 【Settings】 icon, find the 【Software Update】 , and tap the 【Check for updates】 button to check for new software version.

If there is a new version released, then tap 【Download Update】 button to download and update the new software.

(**Note:** Make sure the battery is full before updating, do not use the pen during the update progress to avoid any damage.)

## 3. Usage Notice

### ⦿ Safety:

- This product is strictly prohibited from being exposed to direct sunlight or extreme environments such as high temperature and heat.

- This product is not a toy. It is not

suitable for children under 4 years old to use alone. Children should use this product with their parents.

- Do not soak this product and its accessories in liquid.
- Before using the charger, you must check whether the wires, plugs, shells and other parts are damaged. If damage is found, stop using it until the repair is complete.
- This product can only use the recommended power supply (recommended power supply specification: 5V-1A), and the power supply that has obtained BSMI certification and meets the standard requirements should be used.
- Built-in 1050mAh polymer battery cannot be removed or replaced. If damaged, please contact after-sales service and repair it.
- The charger is used by or under adult supervision.
- For the safety of you and your children, we have made charging protection and cannot be used while charging.

## Cautions

1. Non-professionals are not allowed to replace the battery. If the battery is replaced incorrectly, there will be a safety hazard.
2. Only use the same type or equivalent type of battery to replace.
3. For your safety, please do not expose the battery in the product to overheating environments such as the sun or fire.


## © Troubleshooting

Error	Solution
Boot failed	Charge the pen
Computer can't detect the pen	Use the specific USB cable
Won't read out after scanning	Turn off the mute function in the Dictionary Lookup
No Live traslation	Please connect to a WIFI network
Touch screen doesn't respond	Long press the power button for 10 seconds to force shutdown and boot again
No scan results	Scan with the correct pen holding posture
Others	Contact customer service



# WorldPenScan Go

## User Manual



This manual contains important information, please keep it for future use.

## **FCC Requirement**

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.