



• BLUETOOTH INSTRUCTION (NOTE: THE DEVICE IS GOIF, PAIR CODE: 0000

- Long press the "Power on/off" button 3 seconds, hear the prompt sound and the blue indicator flash quickly and it means that it has entered Bluetooth paring status.
- Starting up the Bluetooth function of mobile phone to search for Bluetooth device (Golf), select it and it will be prompted for a password (Note: some mobile phone can be connected directly without entering pairing code), enter "0000" number, press "Yes" to connect the Bluetooth device (Golf).
- 3. The Golf speaker is ready for use.
- 4. Bluetooth re-connection
- a. When the phone and Bluetooth communication beyond the effective range (≥10M), it will be

disconnected. After the phone back to the effective range (≤10M), you have to reconnect phone and Bluetooth to make it work again.

b. When Bluetooth power is cut off, re–switch to the Bluetooth status, select Bluetooth to connect.

CHARGING THE BATTERY

- When battery is low, the Bluetooth speaker will make a beep every 30seconds during playing music, please recharge it in time to continuous use.
- Plug the provided USB charging cable into the speaker and an active computer USB port or a USB AC adapter that is plugged into an active wall outlet.
- 3. Charging time: 2-2.5hours

SPECIFICATIONS:

Speaker: D36mm (180HZ-20KHZ)

SNR: ≥88 ± 3dB

Bluetooth version: 3.0

Bluetooth effective range: up to 10meters

Polymer battery: 250mAh Playing time: 4–5hours Charging voltage: DC5V

Product size: 46mm(D)*60mm(H)

Single weight:45g

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.