

75mm

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

04

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.



封底

MOBILE ODYSSEY

DUKE WATERPROOF BLUETOOTH SPEAKER

USER'S MANUAL

LED INDICATOR



DC 5V

FCC ID: QIFB29



封面

What's in the Box?

- Waterproof Bluetooth Speaker
- USB/DC 5V Cable for Charging
- User Operating Manual
- Storage Pouch

Bluetooth Speaker Operation

Note: Select "DUKE"

Pairing Code is: 0000

- Powering on the Speaker:
 1. Press and hold the "⏻" button.
 2. When the prompt tone sounds and the blue and red LED indicators flash alternately, the speaker is powered on and ready for pairing.
- Pairing a Device to the Bluetooth Speaker:
 1. On the device to be paired (phone, tablet, etc.), select Bluetooth device "DUKE".
 2. If prompted for a password, enter the pairing code "0000", and confirm the connection. Note that some devices can be connected directly without entering a pairing code.

01

- To increase or decrease volume, press and hold the "+/−" buttons.
- To skip or go back in tracks, press and release the "+/−" buttons.
- To play or pause, press the "▶▶" button.
- To answer a call when connected to a mobile phone, press the "☎" button. Press again to hang up the call or double click to return the most recent incoming call.

Bluetooth Reconnection

1. When the device and Bluetooth speaker are separated beyond the effective range (≥30 ft.), the Bluetooth communication will be disconnected.
2. Return the device to the effective range (≥30 ft.) to reconnect with the Bluetooth speaker.

- To power off the speaker, press and hold the "⏻" button.

Charging the Battery

- Plug the provided USB charging cable into the DC 5V port and connect to an active computer USB port, USB AC adapter, USB car charger or portable charger.
- While charging the LED indicator turns red. Once charged, LED turns off.
- Typical charging time: 2-3 hours.

02

Specifications

Transmitting Frequency:	2.4G Hz
Charging Time:	approx. 3 hours
Bluetooth version:	2.1 + EDR
Bluetooth effective range:	up to 30 ft
Battery:	3.7V 400mAh Lithium
Playing time:	up to 6 hours
Charging voltage:	DC5V/100-120mA
Unit Weight:	approx. 0.1kg

Safety Information:

- Avoid sources of intense heat or flame.
- Do not insert metal objects into item. (Short circuit risk).
- Do not attempt to repair the device. Rather, contact a service professional.

03

A、B正反面印刷