





成品尺寸：50x65mm  
 材质：正反面印刷，128G双铜纸

正面

|  |  |  |
|--|--|--|
| <p style="text-align: center;"><b>Sonic Capsule</b><br/>Bluetooth Earbuds</p> <hr/> <p style="text-align: center;"><b>Instruction Sheet</b></p>  <p><b>In the Box:</b></p> <ul style="list-style-type: none"> <li>2 x Earbuds</li> <li>1 x Charging Cradle</li> <li>1 x USB-C Charging Cable</li> </ul> | <p><b>Controls:</b></p> <p><b>Earbuds</b></p>  <p><b>Charging Cradle</b></p>  <p><b>Charging Cradle Back</b></p>  | <p><b>POWER ON</b></p> <p>Press and hold the Multi-function button for about 3 seconds, hear prompt "Power on", Blue light flash</p> <p><b>TWE pairing</b></p> <ol style="list-style-type: none"> <li>1. Keep the distance between the device and the Bluetooth Earbuds within 3 feet (for pairing only)</li> <li>2. Press and hold the multi-function button on both earbuds for a few seconds until you hear prompt "Power on", and see blue lights flashing</li> <li>3. You will hear prompt "Left Channel" on Left Earbud and "Right Channel" on Right Earbud to begin pairing.</li> </ol> <p><b>Connect TWE to your device</b></p> <p>Active the Bluetooth function on your device to search the "Sonic Capsule" and connect to it. You will hear "Pairing success, sort connected" from the Master Earbud (Right Earbud-Factory default setting), and blue lights flashing. It is ready for use.</p> <div style="border: 1px solid black; padding: 5px;"> <p><b>NOTE:</b><br/>             Factory default setting is RIGHT Earbud as MASTER Earbud. To reset/change MASTER Earbud, hold multi-function button on BOTH earbuds for 6 seconds. When blue/red lights flash quickly, press multi-function button twice on the earbud you want to set as the MASTER Earbud.</p> </div> |
|--|--|--|

反面

|   |  |  |
|---|--|--|
| <p><b>POWER OFF</b></p> <p>Long press the Multi-function button for about 4 seconds, hear "Power off", the two earbuds will power off together.</p> <p><b>HANDS FREE FUNCTION</b></p> <p>Short press the multi-function button to answer an incoming call / end an ongoing call;<br/>         Long press the multi-function button to refuse an incoming call<br/>         Double press the multi-function button to call the number that last called you<br/>         REMARK: the operation only support master earpiece.</p> <p><b>SINGEL EARBUD PAIRING</b></p> <ol style="list-style-type: none"> <li>1. Press and hold the multi-function button for about 6 seconds, until you hear "Power on" then "Pairing", the blue/red lights flash quickly. (the other Earbud should be off during this process.)</li> <li>2. Active the Bluetooth function on your device to search the "Sonic Capsule" and connect to it.</li> <li>3. You will hear prompt "Pairing success, sort connected". It is ready for use.</li> </ol> | <p><b>CHARGING THE BLUETOOTH EARBUDS</b></p> <p><b>Please fully charge before first use</b></p> <p>To charge your earbuds: simply return them to the charging station, Press the Power button one time and the LED on charging station show blue, and close the lid. While charging, the earbuds's LED show red color, it become blue color after full charged.<br/>         Charging time: around 1-1.5 hours<br/>         Play time: 2hours</p> <p><b>CHARGE YOUR CHARGING STATION</b></p> <p>Plug the provided micro USB charging cable into the charging station and an active computer USB port or USB AC adapter that is plugged into an active wall outlet. The LED light is red color and will die out after full charged.<br/>         Charging time: 2 hours</p> | <p><b>PRODUCT'S SPECIFICATIONS</b></p> <p>Bluetooth version: 4.2<br/>         Speakers: D8mm *2<br/>         Frequency response: 200HZ-200KHZ<br/>         Battery build-in earpiece: 40mAh*2<br/>         Charging Station battery: 600mAh<br/>         Charging current: 60mA DC 5V</p> <p><small>NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</small></p> <ul style="list-style-type: none"> <li>- Reorient or relocate the receiving antenna.</li> <li>- Increase the separation between the equipment and receiver.</li> <li>- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.</li> <li>- Consult the dealer or an experienced radio/TV technician for help</li> </ul> <p><small>Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:<br/>         (1) this device may not cause harmful interference, and<br/>         (2) this device must accept any interference received, including interference that may cause undesired operation.</small></p> |
|---|--|--|