


Photographs module 20114433301 rev. 1.0

Internal

PHOTOGRAPH 1: - <i>MTW SENSOR, INTERNAL VIEW</i>	2
PHOTOGRAPH 2: - <i>MTW SENSOR, BATTERY VIEW</i>	3
PHOTOGRAPH 3: - <i>MTW SENSOR, TOP VIEW OF PCB</i>	4
PHOTOGRAPH 4: - <i>MTW SENSOR, BOTTOM VIEW OF PCB</i>	5
PHOTOGRAPH 5: - <i>INTERNAL VIEW OF AWNDDNG WIRELESS DONGLE</i>	6
PHOTOGRAPH 6: - <i>TOP VIEW OF AWNDDNG WIRELESS DONGLE PCB</i>	7
PHOTOGRAPH 7: - <i>BOTTOM VIEW OF AWNDDNG WIRELESS DONGLE PCB</i>	8

Photograph 1: - MTw sensor, internal view




Photograph 2: - MTw sensor, battery view




Photograph 3: - MTw sensor, top view of PCB




Photograph 4: - MTw sensor, bottom view of PCB



Photograph 5: - *Internal view of AWNDDNG Wireless dongle*



Photograph 6: - *Top view of AWNDDNG Wireless dongle PCB*



Photograph 7: - *Bottom view of AWNDDNG Wireless dongle PCB*

