#### <sup>MIS</sup>TX bn928A i9w6uH



# betrsted started

AT&T**4** -Star Eco-Rating 2.0



On the home screen, touch Apps > Settings > Battery.

You can:

BC

- View detailed battery usage statistics. Optimize battery use to reduce power
- consumption. • Select a suitable power saving mode according to the remaining battery.

C Battery	<ul> <li>More power saving settings</li> </ul>	
42		
(hep-		
Power saving mode 1 0 0 km Initia too Convert and entirely, disables among address and another serveds, and induces invalid physics is serve proved		
Litra 3 d 1 bien Ody settert appt det erstellite ( museemende) what the bishary level (a tat)		
POWER SAVING FROM APPS		
Lock screen cleanup If ages set the above after screen is to the	<ul> <li>Keep or stop apps running after the screen is turned off</li> </ul>	
Power intensive apps 1		
SCHEEN POWER SAVING		
Low resolution power saving Lower the increase localization of instant to two:		
OTHERS	Applications consuming the most power	
Consumption level		

#### Useful Apps\*

Remaining battery percentage

#### AT&T DriveMode

Stay safe while driving. Stop incoming calls and text messages.

Check for power consumption

issues and automatically

optimize performance


#### AT&T Protect Plus

Backup and access your photos, videos, and contacts. Locate your lost phone or remotely lock it. And live support is seconds away.

## AT&T Call Protect

Use the power of the AT&T network to automatically block fraud calls and warn about suspected spam calls.

## Setup & Transfer



\*Compatible device and subscription may be required. Data and messaging rates may apply. Restrictions and limitations may apply. For more app information, go to https://att.com/shop/apps.

#### What else is in the box?

- Huawei Ascend XT<sup>2™</sup>
- Pre-installed SIM
- Li-ion Polymer Battery (non-removable)
- Power Adapter
- USB Data Cable



## **Find More Information**

#### Manage Your Account with myAT&T

On your phone: Apps > myAT&T • On the web: att.com/myATT



Compatible device and online account required. Data and messaging rates may apply for download and app usage.

#### **Need More Help?**

- On your phone:
- Apps > Device Help • On the web: att.com/DeviceHowTo

#### Give us a Call

- 611 from any AT&T wireless phone
- 800.331.0500 or prepaid 800.901.9878



# - FCC ID: QISH1711. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may

cause undesired operation. 繼 , 🦇 , المسعد and Huawei Ascence

att.com/ecospace See below for details

AT&T Eco Rating 2.0 only applies to Huawei Ascend XT<sup>2™</sup> For limited factors evaluated visit att.com/EcoSpace.

Wireless Emergency Alerts is a registered Trademark and Service Mark of CTIA.

Product meets FCC Radio Frequency Exposure Guidelines

XT<sup>2™</sup> are trademarks or registered trademarks of Huawei Technologies Co., Ltd. LTE is a trademark of ETSI. 4G LTE not avail. everywhere. Contains Li-ion polymer battery -recycle or dispose of properly. ©2017 AT&T Intellectual Property. All rights reserved. AT&T, the AT&T logo and all the 4T&T model or contained begins are trademarke of other AT&T marks contained herein are trademarks of AT&T Intellectual Property. All other marks are the property of their respective owners.

Printed in USA






#### How to replace the SIM

#### Install a SIM/ microSD

Follow the instructions below to install a nano-SIM card and microSD card. Then press and hold the **Power button** to turn on your phone. Your new SIM card is pre-installed. If you are an existing AT&T customer, replace it with your current SIM (see instructions below).



- 1. To remove the card tray, insert the SIM eject pin included with your phone into the small hole next to the card tray.
- 2. Insert a nano-SIM card or microSD card into the card tray.

3. Insert the card tray back into your phone in the correct orientation.

#### Turn on your new phone

Press and hold the **Power button** until the device turns on.

# **Easily Adjust Settings**

#### Settings Menu

On the home screen, touch Apps > Settings.

Settings		
10	and the provest	
0	Airplane mode	
	30.43	.003
۵	Bluetooth	1,063
۲	Mobile data	
8	More	

#### **Quick Settings**

The shortcuts tab allows for guick access to some of your phone's most used features and can be customized.

1. Swipe down from the status bar 2. Touch 🕸 to go to the **Settings** menu.



## **Call Family & Friends**

#### Make a Call

1. From the home screen, touch **Dialer** 🔕 . 2. Make a call using the keypad, call logs or contacts.



#### **Check Voicemail**

1. From the home screen, touch **Dialer S**. 2. Touch and to check voicemail.

#### Visual Voicemail

From the home screen, touch **Apps** > **S Visual** Voicemail, and then select a message to play.

#### Capture Life's Moments

#### Take a Picture

1. On the home screen, touch **Camera** 2. Frame the scene you want to capture. 3. Touch 💿.

#### Record a Video

- 1. On the home screen, touch **Camera** . 2. Touch **O** to select **Video**.
- Touch 💌 to start recording.
- Touch log to take a picture while recording.
- Touch 🕕 to pause recording.
- Touch 🖲 to stop recording.

#### Share a Picture or Video

- 1. On the home screen, touch Gallery 😬.
- Select the photo or video that you want to share. 3. Touch L, choose a sharing method, and follow the onscreen instructions to share your photo or video.

#### Surf & Stream in no time

#### Connect to Wi-Fi

On the home screen, flick down from the status bar and touch 🛜 to turn on Wi-Fi. Touch and hold network.



#### Use Bluetooth

On the home screen, flick down from the status bar and touch ≱ to turn on Bluetooth. Touch and hold  $\circledast$  to go to the Bluetooth menu in **Settings**.

