

Thank you for choosing the HUAWEI HW01 Cradle!


The HW01, a Mobile WiFi accessory, can be connected to a power supply to charge a Mobile WiFi, or connected to the Internet via Ethernet.

- Before you use the HW01, read this manual carefully.
- Pictures in this manual are for your reference only.

Copyright © Huawei Technologies Co., Ltd. 2014. All rights reserved.

THIS DOCUMENT IS FOR INFORMATION PURPOSE ONLY, AND DOES NOT CONSTITUTE ANY KIND OF WARRANTIES.

Appearance



Ethernet indicator

- Blue: An Ethernet connection has been set up.
- Blinking: Setting an Ethernet connection or data is transferring.

Ethernet port

- Connect to the router.
- Connect to the computer.

Using the HW01



Scenario 1: Accessing the Internet Using a LTE or 3G Network



Scenario 2: Accessing the Internet Using Ethernet (WAN)



Recharging a Mobile WiFi Using a Single HW01

Note that the HW01 does not have a battery and cannot be used independently to charge a Mobile WiFi. To use the HW01 as a charger, connect the HW01 to a power supply.


Recharging a Mobile WiFi by Connecting the HW01 to a Power Adapter

1. Place the Mobile WiFi on the HW01.
2. Connect one end of the power adapter to the HW01.
3. Connect the other end of the power adapter to the power socket.



Recharging a Mobile WiFi by Connecting the HW01 to a Computer

1. Place the Mobile WiFi on the HW01.
2. Connect one end of the USB cable to the HW01.
3. Connect the other end of the USB cable to the computer.



Specifications

- Input: 5.0 V DC, up to 2.0 A
- Output: 5.0 V DC, up to 2.0 A
- Dimensions (H x W x D): 110 mm x 90 mm x 36 mm

Environmental Requirements for Using the Device

- Ensure that your hands are dry during connecting and disconnecting cables.
- Keep the device far from sources of heat and fire, such as a heater or a candle.
- Keep the device far from electronic appliances that generate strong magnetic or electric fields, such as a microwave oven or a refrigerator.
- Place the device on a stable surface.
- Place the device in a cool and well-ventilated area. Do not expose the device to direct sunlight.

Maintenance

- If the device is not used for a long time, power it off, and then remove all the cables connected to it.
- Do not trample, pull, or overbend any cable. Otherwise, the cable may get damaged, causing

malfunction of the device.

- Before cleaning the device, stop using it, power it off, and then remove all the cables connected to it.
- Use a clean, soft, and dry cloth to clean the device shell. Do not use any cleaning agent or spray to clean the device shell.

V100R001_01