

Congratulations



You've just purchased the only true stealth radar laser detector with GPS intelligence, extreme range and instant Bluetooth® connectivity to the award-winning ESCORT Live speed trap app.

Go to EscortRadar.com for the full featured RedLine EX Owner's Manual.



Guía de Referencia Rápida Española traducida y manual con todas las funciones también son disponibles a www.EscortRadar.com

EXTREME PERFORMANCE RADAR • LASER DETECTOR

RedLine EX Features

- Dual radar antennas provide the longest possible warning in all directions on all radar bands. Multiple high-performance laser sensors provide maximum laser warning and off-axis protection.
- Exclusive TotalShield™ Technology makes the RedLine EX totally undetectable by any radar detector (RDD).
- Updatable RT Filter™ automatically reduces false alerts from moving In-Vehicle Technology sources such as collision avoidance systems and adaptive cruise control.
- GPS location-based intelligence automatically locks out false alerts and allows you to mark locations for future reference.



Access to ESCORT's DEFENDER Database, which warns you of verified speed traps, speed cameras, and red light cameras.

Built-in Bluetooth® technology gives you access to ESCORT's award winning app, ESCORT Live. Our exclusive real-time ticket-protection, the network which warns you of upcoming alerts received and reported by other users in the area, and gives you access to local speed limit data for over-speed alerts.



Registration and ESCORT Live

Before downloading ESCORT Live, you must first register your RedLine EX device. Be sure to have your RedLine EX unit nearby, as you will need the serial number.

- 1 Visit www.EscortRadar.com and click Product Registration.
- 2 Click the "Registration for all devices" link.
- 3 Follow the onscreen instructions to register your device.
- 4 Press the **RedLine EX** device entry.
- 5 The Bluetooth icon on the RedLine EX display will appear to confirm that it is paired to your smartphone.


Be sure to write down the username and password you create, as you will need this information, once you have registered your device.

- For iPhone:**
- 1 Ensure RedLine EX power is ON
 - 2 Open the App Store on your iPhone and search for **ESCORT Live Radar**.
 - 3 Follow the onscreen instructions to download **ESCORT Live Radar** and then open the app.
 - 4 When prompted, enter the username and password you created when registering your product at EscortRadar.com.
 - 5 Press the Settings button then select **Devices**.
 - 6 You should see **RedLine EX** listed with Not Connected underneath. Press the **RedLine EX** device entry and when prompted select **Pair**.
 - 7 The Bluetooth icon on the RedLine EX display will appear to confirm that it is paired to your iPhone.



For Android based smartphones:

- 1 Ensure RedLine EX power is ON.
- 2 On your smartphone go to Bluetooth® Settings and make sure that Bluetooth is ON.
- 3 Press Scan for devices and wait for the device list to populate. **RedLine EX** should appear under Available devices.
- 4 Press the **RedLine EX** device entry.
- 5 The Bluetooth icon on the RedLine EX display will appear to confirm that it is paired to your smartphone.
- 6 Open Google Play on your smartphone and search for **Escort Live Radar**.
- 7 Follow the onscreen instructions to download **Escort Live Radar** and then open the app.
- 8 When prompted, enter the username and password you created when registering your product at EscortRadar.com.
- 9 Open the app, walk through the tutorial, and you're ready to hit the road!




Installation

Your new detector comes with our latest **EZ Mag Mount™**. Simply tilt the display end of the detector up and slide it onto the mounting bracket. The magnetic mount holds the detector in place. To remove the detector from the mount, simply lift the display end of the detector and the detector releases from the mount.

- Mounting Tips:**
- Center of windshield between driver and passenger.
 - Ensure clear view of road ahead and sky above.
 - Avoid windshield wipers and heavily tinted areas.


To mount the detector in your vehicle:

- 1 Remove paper backing from EZ Mag Mount™ StickyCup.
- 2 Ensure the locking clamp is open.



- 3 Firmly press EZ Mag Mount™ StickyCup onto windshield and close the locking clamp to secure.
- 4 To adjust view, loosen thumb wheel and adjust angle of mounting bracket. Tighten thumb wheel to secure.
- 5 Tilt the display end of the detector slightly upward and engage with the flanged edge of the mounting bracket. The EZ Mag Mount™ magnet holds the detector in place.
- 6 To remove the detector, simply lift the display end of the detector upward. The RedLine EX will release from the mount.
- 7 To remove mount from windshield, release locking clamp and pull tabs on top of StickyCup.

EZ Mag Mount™ Care Instructions:
Should the EZ Mag Mount™ StickyCup accumulate debris and lose its stickiness, simply rinse under warm water, gently wipe off debris and allow to air dry.




Controls & Features

Using RedLine EX

- 1 Plug small end of SmartCard USB into modular jack on RedLine EX and large end of SmartCard USB into your car's lighter/accessory socket.
- 2 RedLine EX should power on automatically. If not, press the device's PWR button.

NOTE: You can easily access and customize all of your Settings and Preferences by pressing and holding the MARK and SENS buttons. See Settings & Preferences for details.

- Alert Light:** Blinks red when receiving a radar or laser alert.
- Power Light:** Lights green when receiving power.
- USB Charging Port:** Charge smartphones, tablets and other USB-charged Devices.



- Earphone Jack:** Connects to optional 3.5 mm stereo earphone
- Mini USB Jack:** Connects to your computer via USB A / Mini B cable for downloading software updates
- Modular Jack:** Connects to SmartCard USB for powering your device

Using SmartCard USB

- Mute Button:**
 - Press to mute the audio for a specific alert.
 - Press three times to lock out a false alert.
 - Press twice while receiving a locked-out alert to unlock.
- When connected to ESCORT Live press and hold mute button on unit or cord to manually report to other users a verified X or K-band alert, or a police officer observing traffic.

Alert Light: Blinks red when receiving a radar or laser alert.

- Power Light:** Lights green when receiving power.
- USB Charging Port:** Charge smartphones, tablets and other USB-charged Devices.



- Modular Connector:** Plugs into detector jack
- SmartCard USB Adapter:** Connects to lighter/accessory socket

Controls & Features

Mute


Press to mute an alert; press three times to lock out a false alert; press twice while receiving a locked-out alert to unlock.

Alert Light: Blinks red when receiving a radar or laser alert.

- Power Light:** Lights green when receiving power.
- USB Charging Port:** Charge smartphones, tablets and other USB-charged Devices.



- Mount Area:** The EZ Mag Mount™ attaches to device here
- Display:** Alert area
- Display:** Current speed
- Volume:** Press and hold + or - to adjust volume
- Sensitivity (SENS):** Press to adjust detector sensitivity (Auto, Auto NoK, AutoLoK, and Highway)
- Mark Location (MARK):** To mark a location for future alerts, press MARK twice, then VOL+ or - to select the type of marker, then MARK again to confirm. Press twice while receiving marker alert to unmark
- Brightness (BRT):** Press to adjust display brightness (Min, Med, Max, Auto, Dark)
- PWR:** Press to turn RedLine EX on or off
- Display (OSP):** OverSpeed alert setting that can be adjusted in Preferences. Bluetooth icon will appear on display screen blue when paired to phone and Speed limit data will show here when ESCORT Live App is open



Continued →