

@vidkSigni Guide

Long Range 2.4GHz Wireless Keyboard and Mouse Combo

Package Contents

Keyboard – Front View

1 2 3

3. Low Battery Indicator

1. Volume Down

Mouse – Front View

3. Low Battery / DPI Indicator

4. Scroll Wheel (third button)

1. Left Click

2. Right Click

5. Back Button

6. Forward Button

7. Increase DPI Button

8. Decrease DPI Button

2. Volume Up

- 1 x Wireless Keyboard
- 1 x Wireless Optical Mouse
- 1 x USB Receiver
- 1 x AAA Battery for Keyboard
- 2 x AA Battery for Mouse
- 1 x Quick Start Guide
- 1 x Warranty Card

Overview

Hardware Requirements

Requirements

- Available USB port
- IBM-compatible PC or Mac

Keyboard – Back View


Operating System

- Windows XP (32-bit / 64-bit)
- Windows Vista (32-bit / 64-bit) Windows 7 (32-bit / 64-bit)
- Mac OS X v10.3 or later*

* Some function keys may not work

Start Here

- 1. Battery Cover
- 2. Foldable Legs allow user to adjust the angle of the keyboard
- 3. Drain Holes



Mouse - Back View

- 1. On / Off Switch
- 2. Battery Cover
- 3. USB Receiver Storage



Plug & Play

After the batteries and the USB receiver are installed, the keyboard and mouse can be used. No software is needed!

Battery and Hardware Installation

Keyboard Battery Installation

- Open the battery cover on the back of the keyboard
 Insert the included AAA battery as the diagram on the battery tray indicates
- 3. Close the battery cover

Mouse Battery Installation

- 1. Open the battery cover on the bottom of the mouse
- 2. Insert one, or two of the included AA batteries as the diagram on the battery trav indicates*
- 3. Close the battery cover

USB Receiver Installation

- 1. Plug the USB receiver into an available USB port on your computer
- 2. Your Operating System will start to install the device driver automatically 3. No additional software is needed. Enjoy your new keyboard and mouse!
- * Weight Control Energy Management

The mouse can be used with one or two AA batteries. Users can adjust the mouse weight by inserting either one or two AA batteries. Using two batteries doubles the battery life to 1 year with normal use. Battery performance may vary depending on usage.

Customize Mouse DPI

The mouse is equipped with a customizable DPI switch. The default setting is 1500 DPI. Simply adjust the DPI sensitivity to your liking by pressing the +/-buttons on the mouse. Pressing the +/-buttons will adjust LED to Red, Green,

Each color represents a different DPI value;

Red: 1000 DPI Green: 1500 DPI Orange: 2000 DPI

All other devices shall bear the following statement in a conspicuous location or device:

This device complies with Part 15 of the FCC Rules. Operation is subject

to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including

interference that may cause undesired operation. FCC Caution:

"Changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment."

ÓIOGEAR