

Limited Warranty

WE'RE HERE TO HELP YOU! NEED ASSISTANCE SETTING UP THIS PRODUCT?

Make sure you:
 1. Use the product at www.iogear.com to try and solve any issues you may be having with the product.
 2. Visit the Tech Blog (www.iogear.com/techblog) on www.iogear.com (under the Support tab).
 3. Call the 24/7 Tech Support Line at 1-866-444-4327 (U.S. only) or 1-866-444-5472.

Warranty Information
 This product carries a 3-Year Limited Warranty. For the terms and conditions of this warranty, please go to <http://www.iogear.com/support/warranty> or call 1-866-444-4327.

Register online at <http://www.iogear.com/register>

Important Product Information
 Product Model _____
 Serial Number _____

Contact

IOGEAR Inc.
 Address: 231 Hanks, Irvine, CA 92618 USA
 T: +1 949 444-4327
 Phone: 949-444-5782
 Fax: 949-444-5782
 Email: support@iogear.com



About Us

- FUN**
IOGEAR offers connectivity solutions that are innovative, fun, and stylish. Helping people enjoy life by using our high technology products.
- GREEN**
IOGEAR is an environmental conscious company that emphasizes the importance of conserving natural resources. The use of our technology solutions helps reduce electronic waste.
- HEALTH**
IOGEAR supports health and wellness. Its ergonomic products with the latest scientific developments, designed to improve the lives of its customers.



Quick Start Guide

Long Range Media Center Desktop Combo

© 2008 IOGEAR, INC.

0905018
0107

Welcome

Thank you for purchasing the 2.4GHz Wireless RF Media Center Keyboard/Mouse Combo. Enjoy the freedom of wireless connectivity with IOGEAR's wireless keyboard/mouse combo. The keyboard and mouse allow you to work up to 33 feet away from the USB receiver connected to your computer. In addition, the mouse provides great accuracy over most surfaces and maintains hand movement due to its 6500 dpi resolution. Enjoy internet and teleconferencing control of your entertainment center with Media Center features of this combo. The different hotkeys give you quick access to some of your most common Media Center tasks such as My PC, My Music, My Video, and My Picture. Additional hotkeys allow users to Play/Pause, Volume Down, Volume Up, and Mute.

Package Contains

- 1 X Wireless keyboard
- 1 X Wireless base mouse
- 1 X USB receiver
- 1 X 3.5" USB extension cable
- 1 X Quick Start Guide
- 4 X AAA batteries for both keyboard and mouse

Features

- 2.4GHz RF technology offers greater range up to 33 feet away from the USB receiver, and enables less interference in your WF environment
- 6500 dpi high resolution base mouse delivers precise cursor movement and can be used on most surfaces
- Silent Operation: The keyboard and mouse are silent and long range keyboard makes ideal presentation tool
- Control the entertainment functions with Media Center features on the keyboard
- New! Compact keyboard and mouse with one USB receiver
- New! Designed skin and stylish keyboard provides better tactile feel and accurate response
- Easy installation and running in minutes
- Built System In-lead warranty

Requirements

- Available USB port
- PC compatible (PC or Mac)
- PC System requires Windows 2000/XP/Vista
- Mac System requires MAC OS X 10.2.8 or later

*Media Center hotkeys support XP/MCE and Vista Premium or higher

Hardware Features

Start Here!


1 Keyboard—Front View

- 01 Fn & On/Off switch—Holds Fn key and press ESC key will allow users to turn on/off the keyboard for extended battery life
- 02 MCE Button—Media Center Start key
- 03 My TV
- 04 My Music
- 05 My Video



2 Keyboard—Back View

- 01 Folds Back Keys—Allow you to adjust the angle of the keyboard
- 02 Reset button—press to connect to the receiver
- 03 Battery compartment—insert the two batteries



3 Mouse

- 01 Battery Compartment—insert two batteries
- 02 Connect Button—press to connect to the receiver
- 03 Laser Sensor—8000 dpi laser sensor
- 04 On/Off Switch—turn mouse On/Off for extended battery life
- 05 Battery LED—turn red when batteries are getting low
- 06 Mute/Win/Lock button
- 07 Right-Click



4 USB Receiver

- 01 USB Type-A connector
- 02 Connect button—press this button to connect receiver to keyboard/mouse
- 03 LED status



Federal Communications Commission (FCC) requirements, Part 15
 This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.
 This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 • Reorient or relocate the receiving antenna.
 • Increase the separation between the equipment and receiver.
 • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 • Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following conditions:
 (1) This device may not cause harmful interference.
 (2) This device must accept any interference received, including interference that may cause undesired operation.
 Any changes or modifications (including the antennas) made to this device that cause it not to comply with the above requirements may void the user's authority to operate the equipment.

Hardware Installation

Before using the product, please make sure you have one available USB port reserved for the wireless receiver. The product is plug and play, no software installation required, connect your PC or Mac wireless right out of the box.

1. Setup up the wireless receiver.
 - 1.1 Plug the wireless receiver into available USB port.
 - 1.2 For Windows/Mac OS X, drivers for the mouse, keyboard, and mouse, will be installed automatically.
 - 1.3 Turn the wireless receiver base power on/off. Hold the LED in the receiver until it turns on.
2. Setup the keyboard and mouse.
 - 2.1 Open the keyboard's battery compartment cover and insert two AAA alkaline batteries. Make sure they are properly installed.
 - 2.2 Push the keyboard battery compartment cover and insert two AAA alkaline batteries. Make sure they are properly installed.
 - 2.3 Turn the mouse battery compartment cover and insert two AAA alkaline batteries. Make sure they are properly installed.
 - 2.4 Press the reset button on the wireless receiver. The LED indicator on the receiver will flash. 2.5 Press the reset button on the keyboard/mouse. The LED indicator on the receiver will flash. 2.6 Press the reset button on the mouse. The LED indicator on the receiver will flash. 2.7 Press the reset button on the mouse. The LED indicator on the receiver will flash. 2.8 Press the reset button on the mouse. The LED indicator on the receiver will flash. 2.9 Press the reset button on the mouse. The LED indicator on the receiver will flash.

Once the connection has been established, when you type the keyboard or mouse the mouse around the LED on the receiver will flash. If the keyboard/mouse have made successful connection with the receiver.

Trouble Shooting

1. When the battery indicator lights up, please change the batteries. We recommend using the IOGEAR batteries for best performance.
2. The keyboard/mouse will stop working if the device is not in use for 8 months. When the keyboard/mouse is stopped, please press any function button to wake it up.
3. If your keyboard/mouse cannot work after installation, please check that settings have been properly plugged into your computer's USB port.
4. Make sure you have inserted batteries in the compartment cover.
5. Without any interference, such as other computer peripheral, the working distance between keyboard and receiver is about 33 feet.
6. Using more than two units and interference occurred, please reset connection again by turning the receiver on and off.

Windows Key	Mac Function
ESC	Control
F11/F12	Open CD
Back/Lock	Brightness-
Phone Break	Brightness+
W	Refresh
+	Volume+
-	Volume-
Mute	Mute