

iCreation

BT-129

Product
Information Guide

iCreation Inc.
Unit 202, 3621 High Way 7 East, Markham ON, L3R 0G6 Canada
TM and © iCreation Inc. All rights reserved.

Specifications

Bluetooth Compliance	Bluetooth V 4.0
Frequency Band	2.4~2.4835GHz ISM Spectrum
Modulation	GFSK (Gaussian Frequency Shift Keying)
Operating Range	Up to 10m (indoor)
Battery Capacity	3.7V, 2200mAh
Power Supply	5V, 0.5A
Charging Time	About 3 hours
Standby Time	About 120 hours
Size	141mm*91mm*54mm
Ambient temperature	-20°C ~ 60°C
Humidity	45%~70%

*Design and specifications are subject to change without notice.

Welcome. You are using Waterproof Bluetooth Speaker.

This guide contains helpful information that enables you to enjoy all of the features of your speaker.

Congratulations

Thanks for purchasing the wireless speaker BT-129.

Enjoy this smart product, please read below instructions carefully. It's more than just a Bluetooth Speaker!

Care and Maintenance

1. Do not attempt to service the product yourself. Opening or removing covers may expose you to dangerous voltages or other hazards. Please contact your local reseller before you send the product for repair.
2. Do not use the product in temperature exceed the standard. Extreme temperature will lead to damage of product, decrease of battery capacity or product durability.
3. Keep the product out of the reach of children or animals.
4. Do not use the product close to other wireless devices or radiators.
5. Do not drop the product into the fire, battery explosion will cause personal injury or death.
6. Use the product in proper volume, extremely high volume can be harmful for your ear.
7. Fully charge the product before use if it has not been used for a long period of time.

Troubleshooting

Volume is not high enough

- Increase the volume of mobile phone/device or BT-129 volume.
- Ensure that the mobile phone/device or BT-129 has been charged.

Hearing Distortion

- Lower BT-129, Mobile phone/device volume.
- If low battery capacity, please charge it.

Can not paired with Bluetooth device

- Make sure that your mobile phone/device is compatible with Bluetooth.
- Make sure it's charged up.
- Turn off your BT-129 and mobile phone/device, then power on and reconnect.

Signal loss or distortion

- Move BT-129 to the place near the mobile phone/device.
- Ensure it's charged up.
- Power off the BT-129, Mobile phone/Device, then repower on.

LED Indicator

Speaker Status	LED Status
Power On	Blue LED flash .
Power Off	Red LED stay on for a while and get off.
Pairing	Red LED and Blue LED flash alternately.
Pairing Succeed	Blue LED flashes 4 times along with two beeps.
Standby	Blue LED flashes once every 8 seconds.
Disconnected	Red LED and blue LED flash simultaneously.
Music Playing	Blue LED flashes once every 8 seconds.
During a Call	Blue LED flashes once every 8 seconds.
Incoming Call	Red LED flashes quickly(steadily).
Battery low	Red LED flashes along with triple beeps every 30 seconds.
Charging	Red LED lights steadily.
Full charging	Red LED off.






Contents

Congratulations	Page 1
Care and Maintenance	1
Feature List	3
Layout	4
Use Instrution	6
Battery/Charger	7
Operations	8
LED Indicator	13
Troubleshooting	14
Specifications	15

Features List

1. Clear and crystal sound , superior stereo performance
2. Build-in microphone
3. Loud , clear , deep bass and stable
4. Wrapped by TPU replaceable and colorful skin
5. Waterproof(IPX7), Shockproof and Scratchproof
6. Bluetooth connection (Bluetooth V4.0)
7. Music playing control
8. Voice dialing
9. Bluetooth stereo (A2DP/AVRCP)
10. Low battery clarm (Alarm and LED indicator)
11. LED indicator (Low battery/Charging/full charging)
12. Receiving and rejecting a call by button
13. Last number redial
14. Mute function
15. Multi-function key
16. Bluetooth for 10m distance

Music Playing

After the speaker is connected to your mobile phone via Bluetooth, press  on the speaker to play, press it again to pause. Press  2 seconds to play next song. Press  2 seconds to start over the current song or get backward to the previous song. Press  1 time or press  time to adjust the volume.

Notes:

- The music player build-in your mobile phone is necessary to support this feature.
- Pair and connect your mobile phone with the speaker before using this feature.
- If a call is coming in when you are listening to music, the music will pause automatically and replaced by the incoming-call-tone. Once the call is finished, the music will continue.

Voice Dialing

In standby mode, short press **[+]** and **[▶]** at the same time then you will hear a tone for voice dialing.

Note:

- This function need the support of the mobile phone.

Mute/Un-mute

Press **[+]** and **[-]** at the same time during a call to mute the microphone.


A single beep will follow to indicate success of the operation.

Note:


- There will be two beeps every 5 seconds until you hold these two buttons again to un-mute the microphone.

Layout


Front View




Rear View



Top View




Side View




Calling


Answer a call

Short press  to answer an incoming call.


Reject a call

Press and hold  for 2 seconds to reject the call.

End a call


After calling, short press  to end the call, or end the call on the phone.

Last Number Redial

Short press  2 times to redial the last call.

Pairing and connecting

Enter pairing mode

Press and hold  for 7 seconds. Wait until red LED and blue LED flash alternatively along with two beeps.

Pair

1. Enable Bluetooth function on your phone or other smart devices and search Bluetooth accessories in range.
2. Choose BT-129 when it shows up and get connected (input 0000, if a pairing code is requested).
3. When blue LED flashes 4 times along with two beeps, BT-129 gets connected successfully.




Notes:

- If the pairing is not complete within 5 minutes, the speaker will quit the pairing mode. You need to repeat the steps of pairing again.
- After the connection is successful, if you turn the speaker off and turn it on again, it will be connected to the last connected mobile phone automatically. Also, a beep will be heard.

Disconnect

Power off the BT-129 or disconnect the Bluetooth function on your phone or other smart devices.

Use Instruction

Function Key	Item	Function	Mode	Operate
Multi-Function key/Power On/Off 	One Key	Play/Stop	Music Play	Press Multi-Function key 1 time
		Paired with	Power off	Press Multi-Function key 7 seconds
		Last Number Redial	Standby	Press Multi-Function key 2 times
		Voice Dialing	Standby	Short press Vol+ & Multi-Function key
		Answer a Call	Standby	Press Multi-Function key 1 time
		Reject a Call	Standby	Press Multi-Function key 2 seconds
		End a Call	Call	Press Multi-Function key 1 time
Volume+ (Vol +) 	One Key	Mute Off/On	Call	Short press Vol+ & Vol-
		Next Song	Play	Press Vol+ 2 seconds
		Volume Up	Standby /Call	Press Vol+ 1 time
Volume- (Vol -) 	One Key	Current/ Previous Song	Play	Press Vol - 2 seconds
		Volume Down	Standby /Call	Press Vol - 1 time

Note: This product have 3 keys: Multi-Function key, Volume+, Volume-, Specific Instruction please see above.

Battery/Charger


The speaker has a built-in Li-ion battery (3.7V, 2200mAh), so it can be used without connecting with a power supply(5V,0.5A). To charge the battery, please connect with computer or charger through charging line.


Notes:

- When BT-129 is charging the LED status indicator will be RED. When fully charged the RED status indicator LED will go off.
- From fully discharged battery to fully charged will take 3 hours.
- You can plug the cable to charge BT-129 while still using it when its battery is low, but this can shorten the battery life. It is recommended to power off BT-129 and fully charge it before use.


Operations


Power On / Off

Power On: in power off mode, press and hold  for 4 seconds to power on BT-129. Wait until the blue LED flashes 3 times along with a single beep.

Power Off: in standby status, to power off the device, press and hold  for 3 seconds when it is on . Wait until the red LED off along with a single beep.

Volume Adjust

Volume Up: press  1 time to adjust the volume.

Volume Down: press  1 time to adjust the volume.

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions:

(1) this device may not cause interference,
and (2) this device must accept any interference,
including interference that may cause undesired operation of
the device.

Le présent appareil est conforme aux CNR d'Industrie
Canada applicables aux
appareils radio exempts de licence. L'exploitation est
autorisée aux deux conditions suivantes :

(1) l'appareil ne doit pas produire de brouillage,
et (2) l'utilisateur de l'appareil doit accepter tout brouillage
radioélectrique subi,
même si le brouillage est susceptible d'en compromettre le
fonctionnement.

Compliance statement

1. This device complies with Part 15 of the FCC Rules.
Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.
(2) This device must accept any interference received,
including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the
party responsible for compliance could void the user's
authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the
limits for a Class B digital device,
pursuant to Part 15 of the FCC Rules. These limits are
designed to provide reasonable protection
against harmful interference in a residential installation.

This equipment generates uses and can radiate radio
frequency energy and, if not installed and used
in accordance with the instructions, may cause harmful
interference to radio communications.

However, there is no guarantee that interference will not occur
in a particular installation.

If this equipment does cause harmful interference to radio or
television reception, which can be

determined by turning the equipment off and on, the user is
encouraged to try to correct the

interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from
that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for
help.

This compliance to FCC radiation exposure limits for an uncontrolled
environment, the minimum of 20 cm separation distance shall be
maintained between antenna and body.