

9. SYSTEM TEST CONFIGURATION

Use a block of foam and combined it with EUT wrapping rubber band around it. This way it can test X, Y, and Z axis. To activate continuous transmission, reset jumper and press 8 times on S3 button.



X-Axis



Y-Axis



Z-Axis

Radiated Open Site Test Set-up