







Pic C-1 Front View of EUT









Pic C-2 Back View of EUT

Test positions for Head:

<p>Cheek device with left head phantom.</p>	<p>Tilt device with left head phantom</p>
	
<p>EUT Setup Configuration 1</p>	<p>EUT Setup Configuration 2</p>
<p>Cheek device with right head phantom.</p>	<p>Tilt device with right head phantom</p>
	
<p>EUT Setup Configuration 3</p>	<p>EUT Setup Configuration 4</p>

Test positions for body:

According to the antenna position, the Body SAR is tested at the following 6 test positions all with the distance =10mm between the EUT and the phantom bottom :

Front in body position	Back in body position
	
EUT Setup Configuration 1	EUT Setup Configuration 2
Left Side in body position	Right Side in body position
	
EUT Setup Configuration 3	EUT Setup Configuration 4
Top Side in body position	Bottom Side in body position
	
EUT Setup Configuration 5	EUT Setup Configuration 6