

Test positions for body:

According to the antenna position, the Body SAR is tested at the following 6 test positions all with the distance =0mm between the EUT and the phantom bottom:



Picture 1: Toward Phantom (0mm)



Picture 2: Toward Ground Cheek(0mm)



Picture 3: Toward Ground Tilt (0mm)



Picture 4: Toward Left (0mm)



Picture 5: Toward Right (0mm)



Picture 6: Toward Bottom (0mm)

Test positions for body:

According to the antenna position, the Body SAR is tested at the following 6 test positions all with the distance =5mm between the EUT and the phantom bottom:



Picture 7: Toward Phantom (5mm)



Picture 8: Toward Ground Cheek(5mm)



Picture 8-9: Toward Ground Tilt (5mm)



Picture 10: Toward Left (5mm)



Picture 11: Toward Right (5mm)



Picture 12: Toward Bottom (5mm)