











Cheek device with right head phantom.	Tilt device with right head phantom
	
EUT Setup Configuration 1	EUT Setup Configuration 2
Cheek device with left head phantom.	Tilt device with left head phantom
	
EUT Setup Configuration 3	EUT Setup Configuration 4

Test positions for body:

According to the antenna position, the Body SAR is tested at the following 6 test positions all with the distance =10mm between the EUT and the phantom bottom :

<p style="text-align: center;">Phantom in body position</p> 	<p style="text-align: center;">Ground in body position</p> 
<p style="text-align: center;">EUT Setup Configuration 1</p>	<p style="text-align: center;">EUT Setup Configuration 2</p>
<p style="text-align: center;">Right Side in body position</p>	<p style="text-align: center;">Left Side in body position</p>
	
<p style="text-align: center;">EUT Setup Configuration 3</p>	<p style="text-align: center;">EUT Setup Configuration 4</p>
<p style="text-align: center;">Top Side in body position</p>	<p style="text-align: center;">Bottom Side in body position</p>
	
<p style="text-align: center;">EUT Setup Configuration 5</p>	<p style="text-align: center;">EUT Setup Configuration 6</p>