





2.1.7 Setup Photos




30 - 200 MHz




200 - 1000 MHz







2.2.7 Setup Photos




2.1.7 Setup Photos




Mode 1 Configuration 1 / Setup 3



Mode 1 Configuration 2 / Setup 1




Mode 1 Configuration 2 / Setup 2



Mode 1 Configuration 2 / Setup 3



Mode 2 Configuration 1 / Setup 1



Mode 2 Configuration 1 / Setup 2



Mode 2 Configuration 1 / Setup 3




Mode 2 Configuration 2 / Setup1




Mode 2 Configuration 2 / Setup 2




Mode 2 Configuration 2 / Setup 2




1 - 12 GHz Setup1




1 - 12 GHz Setup 2



1 - 12 GHz Setup 3



1 - 12 GHz Setup 4



2.2.7 Setup Photos

