# azumi


User Guide




#### WELCOME

- Congratulations on your purchase of the Azumi mobile phone. Your phone provides many functions which are practical for daily use, such as a hands-free loudspeaker, camera, MP3 player, Ultra clear video, WIFI and GPS.
- You can read the manual to understand how to use Azumi mobile phone and experience the well-established functions and simple operation method. Please use the original accessory in order to achieve the best use of effects. Azumi shall not be responsible for any damage in machinery due to use of non-original components.


## YOUR PHONE-FRONT VIEW




## YOUR PHONE-BACK VIEW



#### **CHARGE THE BATTERY**



## **INSERT SIM AND MicroSD CARD**



Please insert the SIM card according to the mark on the phone. Make sure that the clipped corner of the SIM card and the metallic contacts are facing the correct direction. Slide the SIM card into the slot until it doesn't move up any further.

At the top of SIM slot is the micro SD card slot. The direction in which the microSD card has to be inserted into the designated slot is shown by an mark on the phone.

#### TURN THE PHONE ON&OFF

Hold down the power button to turn on the phone.

Hold down the power button, then Follow the on-screen instructions to turn off the phone.




## **DIM LOCK & WAKE THE PHONE**

When the power is on and you want to dim the screen, press the power button.
When the screen is dimmed and you want to wake the phone, press the power button and then drag the lock to the right.



## **HOME SCREEN**



## **APPS**





Touch an app to launch it

## **STATUS BAR**

The status bar shows your phone's status and notifications. (Notifications are described on the next page.)



#### **Status icons**

The following status icons may appear on your screen:


lcon	Statement	Icon	Statement
.4	SIM Network signal level		Headset is inserted
	Indicates battery capacity	*	Bluetooth is activated
<u>:</u>	Unread messages	<b>?</b>	Wi-Fi is connected
×	Missed calls	X	Airplane mode is activated
0	Alarm is activated	4	USB is connected

#### **NOTIFICATION PANEL**

The notification panel is your center for new events:like new e-mail,voicemail,updates,and more.


Drag down to display notifications.

Touch a notification to respond.



#### **MAKE & ANSWER A CALL**

- 1. Touch the call icon from Home screen.
- 2. Touch in call screen to show the dial pad, then dial a number.
- 3. Touch to initiate the call.








#### **VOLUME CONTROL WHEN CALLING**

Volume key is at the right side of the phone. During a conversation, you can press the volume key to tune the sound volume.



#### **SEND A TEXT**



- 1. From the Home screen touch
- 2 Taylob
- 2. Touch
- 3. Touch the recipient field, then enter a recipient.
- 4. Touch the Type message field, then enter a message.
- 5. Touch send icon to send text messages.

#### ADD EMAIL ACCOUNTS

The first time you open Email, you are prompted to set up an email account. After that, you can configure Email to send and receive email from additional accounts.

To add an email account: Open the Accounts screen. Touch menu icon and touch Add account. In the Setup Email screen, enter your email address and password. Touch Next. Or, if you need to enter email account settings the wizard can't configure for you, touch Manual setup, you're prompted to enter your email account details. Enter any other information requested by the type of account you're adding and touch Done. Enter a name for the account and touch Done. Email starts downloading your email messages and you can start using it to send and receive messages using the new account.



#### **SET A RINGTONE**


Touch Audio Profiles, select the profiles you want to set, you can customize the ringtone and volume of incoming call, notification ringtone in this interface.

#### Multi-Media

#### **FM RADIO**

- 1. Insert earphone, touch FM Radio, then tap the Power icon to stop or play FM.
- 2. Tap the forward by 0.1 MHz or tap the to change channel frequency. Press volume key to adjust the volume.
- 3. Tap the **1**, you can Search channel, Record FM and other.
- 4. Tap the , you can see all searched channel. Tap and hold to add your favorite channel.

#### **MUSIC PLAYER**



Control				
Play/Pause	Touch ► / II			
Previous/Next	Touch ⊢ / ►			
Volume adjust	Press volume key			
Now playing: Touch to open the current playlist.	Touch ≒			
Shuffle: Touch to shuffle the current playlist.	Touch ×			
Repeat: Touch to repeat the current playlist; touch again to repeat the current track.	Touch 🕏			

**Note:** Do not support copy files of more than 500M to the mobile phone memory.

#### **TAKE A PICTURE**

- 1. Launch the camera by pressing the camera icon on the home screen.
- 2. Press the camera button to take a picture.

#### **SHOOT A VIDEO**

- 1. In the Camera app, select video .
- 2. Press the camera button to begin filming, and press again to stop filming.

#### **CONNECT TO WI-FI NETWORKS**

Wi-Fi is a wireless networking technology that can provide Internet access at distances of up to 100 meters, depending on the Wi-Fi router and your surroundings.

Touch Settings>Wi-Fi. Check Wi-Fi to turn it on. The phone scans for available Wi-Fi networks and displays the names of those it finds. Secured networks are indicated with a Lock icon.



Current boot: 100-900mA

Current Screen: 100-260mA

Screen voltage: 1.8-2.8 Vcc

Current calls: 100-650 mA

Call voltage: 3.6-4.2 Vcc

Voltage Shutdown: 3.4 Vcc

Phone Voltage: 3.7 Vcc

Charger input current and voltage: 100-240Vca, 50-60Hz, 0.2A

Output current and voltage charging head: 5.0Vcc, 650mA

#### 1.FCC Statement

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

#### **SAR Information Statement**

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radiofrequency (RF) energy set by the Federal Communications Commission of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg. \* Tests for SAR are conducted with the phone transmitting at its highest certified

power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output. Before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government adopted requirement for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model. The highest SAR value for this model phone when tested for use at the ear is 0.790W/Kg and when worn on the body, as described in this user guide, is 0.797W/Kg(Body-worn measurements differ among phone models, depending upon available accessories and FCC requirements). The maximum scaled SAR in hotspot mode is 1.304W/Kg. While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement for safe exposure. The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of http://www.fcc.gov/oet/fccid after searching on FCC ID: QRP-AZUMILT40 Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications Industry Asso-ciation (CTIA) web-site at http://www.wow-com.com. \* In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a sub-stantial margin of safety to give additional protection for the public and to account for any variations in measurements.

#### **Body-worn Operation**

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 10mm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.