BOLCK DIAGRAM

RESET IC ELM9722	LCD	USB IC GDS306001 / 48MHz → USB – PORT
KEY	CPU KS3C821 / 8MHz / 32.768KHz	FLASH MEMORY (64M, 128M)
		SPEAKER
MIC – IN	DSP MAS3509 / 18.432MHz	AUDIO – OUT → POWER – AMP NJM2076 / E/P JACK
BATTERY		