

L811 2 In 1 Spray Drift Stunt Car Instruction Manual

Notes:
 -This product is not suitable for children aged 3 or under. When using electrical products, precautions must be taken to prevent the risk of electric shock.
 -Please read the instructions carefully before using the toy for the first time. They contain important information on how to operate the product.
 -There are small parts in this product. The children should play it with the guard of adults, and never swallow the small parts into their mouth.

Thank you for purchasing one of our toy products. To ensure that you get the most out of your purchase, please read these instructions carefully before using the toy for the first time. They contain important information on how to operate the product.

2 In 1 Spray Drift Stunt Car



Inserting the remote control batteries

Remote control

1. Check the ON/OFF switch is in the "OFF" position.
2. Use a screwdriver to loosen the screw.
3. Remove the battery cover.
4. According to the polarity indicated inside in the remote control. Put the 2*AA battery into the battery compartment.
5. Put the battery cover back and tighten the screw.

Remote control car

1. Check the ON/OFF switch is in the "OFF" position.
2. Use a screwdriver to loosen the screw.
3. Remove the battery cover.
4. Install the battery as indicated in the picture on the right.
5. Put the battery cover back and tighten the screw.

Note: If breakdown occurs in the product, please take out the battery for one minute, and then reinsert it. If the breakdown still exists, please replace the battery. The battery can only be installed by the adults.

Car assemble and disassemble instructions

Front car **Back car**

Combine the car, align the position of the card slot, and push forward. Easy to buckle and connect.

Separate switch

Separate the car, press the switch and pull it back. The car separates easily.

Spray water instructions: Only back car has spray function.

1. Open the lid
2. Add purified water
3. Spray button

Care and maintenance


- Remove the batteries when you do not plan to use the toy for an extended period.
 - Wipe the vehicle clean with a damp cloth.
 - Do not expose the toy to high temperatures, moisture or direct sunlight.
 - Do not immerse the toy in water, as this may damage the electrical components.
 - If the wheels is too dirty or rolls inflexibly, this may influence the operation experience.
- Please check it and clear up the foreign matters.

Caution

- When the wheels of remote control car is rolling. Do not touch it in order to avoid injury of yourself or damage of the car.
- Please do not play by the road or in dangerous places in case of accidents.
- Avoid operating the car in the rain or grinding the remote control vehicle over the puddle in case of breakdown.
- Avoid operating the vehicle alongside the river, lake or pond in case the remote control or remote control vehicle fall into the water.
- If recharging is unnecessary, please take the battery out of the remote control vehicle and remote control.
- The car will get a poor rolling effect if play on the carpet.



Introduce the function of the remote control and the car



Auto demo: Short press the auto demo to start the automatic demonstration, when in this mode, the remote control vehicle will perform each kind of key function automatically. Press any key to exit the auto demo.

Spray function: After spray water tank. Press the button and the rear part of the car will be sprayed.

Using the car

Turn on the power of the remote control.
 Turn on the remote control car switch to turn on the remote control car, so that the remote control and the remote control car will be successfully linked, you can operate remote control car.
 Turn off the switches of the car and the remote control after use.
 The independent driving time of the car in front of the remote control car is about 22 minutes, and the independent driving time of the car behind is about 22 minutes. The independent driving time of the combined car is about 22 minutes.
 The control distance of the remote control car should not exceed 30 meters, otherwise it may lose control.
 When the spray function is filled with water, it can be sprayed for about 4-5 minutes.

NOTICE:

1. When the car is combined, it is necessary to turn on the switches of two cars and turn on a remote control.
2. When the car is separate, the remote control shall preferentially match the car that is started first. If the two cars are started at the same time, then priority is given to matching the front car.
3. To avoid losing the remote control car or getting out of control, always follow the following steps: A. Turn on the remote control. B. Turn on the remote control car. Follow the reverse procedure to close.

Charging the batteries

A. Sketch map of the recharging in a car battery

B. Battery charging

- Insert the USB charging into the socket. Insert the battery plug into the plug of the USB cable. (Pay attention not to confuse the positive and negative polarity.)
- A full charge takes 90 minutes. When charging the LED indicator turns into red, when charging is complete, the LED indicator stays off.
- Regularly inspect the toy, battery charger, charging cable, connectors and other components for signs of damage. In the event of any damage, discontinue use and send the parts for repair.
- In case of abnormal responses such as suspicious peculiar smell, noise or smog in the charger, please remove the power supply at once.
- Please recharge with the dedicated USB delivered by the original factory. Never use broken USB or USB of other brands.
- Please do not recharge the swelling, leaking or broken battery.
- Please do not overcharge the battery. When the battery is fully recharged, please pull out the charger.
- Please do not recharge on the surface of the objects near inflammable things (carpet, wood floor solid wood furniture, etc.) or of conductive things. While recharging, please keep the battery within the range of visibility.

Battery safety information

1. The batteries must only be charged under adult supervision.
2. Before charging the batteries, remove the battery compartment from the vehicle chassis.
3. Remove empty batteries from the vehicle and remote control.
4. Ensure that the vehicle is switched off before inserting the batteries.
5. Install the battery according to the instruction inside the battery box. Make sure not to confuse the positive and negative polarity of the battery.
6. Do not attempt to charge non-rechargeable batteries.
7. Do not short circuit the battery terminals.
8. If you do not plan to use the vehicle for an extended period, remove the batteries from the vehicle and remote control to prevent leakage.
9. Do not throw batteries into open flames, as this may cause them to explode or leak.
10. Do not mix old and new batteries or batteries from different manufacturers.
11. Only use batteries from recommended or reputable manufacturers.
12. Regularly inspect the batteries for signs of leakage.
13. It is suggested not to use more than 3 batteries for one single play.
14. If leaking occurs in the battery, please avoid touching the liquid with the skin and eyes. If it touches the skin, please clean the skin with soap and clean water at once. If it touches the eyes, please wash the eyes with a lot of cold water at once and see the doctor right away.
15. This equipment is composed of electronic components and battery. The electric appliance garbage should be given special care according to the local requirements for garbage disposal.
16. Keep this instruction manual in a safe place for future reference. It contains important information on how to use the product safely.

Introduce the function and operation of front and back car

Forward 	Backward
360° left rotation 	360° right rotation
Left front steering 	Right back steering
Right front steering 	Left back steering

Introduce the function and operation of combination car

Forward 	Left front 45 degree traverse 	Left traverse
Backward 	Front right 45 degree traverse 	Right traverse
Left rear 45 degree traverse 	360° left rotation 	Left front steering
Right rear 45 degree traverse 	360° right rotation 	Right front steering
Right back steering 	Left back steering 	AUTO DEMO

FCC compliance statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

EIRP(MAX): -3.75dBm (for EU)

RF frequency range: 2414.4MHz-2474.4MHz