



## Use manual

Wi-Fi 2.4G frequency range : 2412MHz for 11b/g/n(HT20)	
ANTENNA TYPE : Wire Antenna	
<b>Senor</b>	
Senor	CMOS, 1/5" color
resolution ratio	640*480 (300k pixel)
focal length	3.6mm
Lens focal diameter ratio	F2.4
viewing angle	60。
minimum illumination	<a href="#">1.0Lux@550nm</a>
<b>video</b>	
Image coding format	H.264
image resolution;	VGA (640x480) / QVGA (320x240) /QQVGA(160x120)
Maximum transmission rate of image	25fps
Light frequency	50Hz、60Hz、Indoor and outdoor adaptive
V-REV	Vertical and horizontal image flip
AWB	SUPPORTING
<b>Wireless</b>	
network interface;	IEEE802.11b/g/n
antenna gain	2.0dB
Working model	AP
<b>networking protocol;</b>	
networking protocol;	TCP/IP, DHCP, SMPT, HTTP, DDNS, UPNP
working temperature	0 - 50C° , 20% - 80%
storage temperature	-10°C ~ 60°, 0% - 90%
working voltage	3.3V ~ 5V
working current	200mA ~ 250mA
OPERATION DISTANCE:	2-3M




Body




Camera

### Camera's Installation and Dismantling Methods

#### Camera's installation procedures:



1. Connect the camera's wire connector to the drone.




2. Place the camera into the drone and rotate the camera counterclockwise to lock.

#### Camera's dismantling procedures:



1. Rotate the camera in the clockwise direction.



2. Take out the camera upward and disconnect the wire connector from the drone.

Search and install APP "WIFI GO", switch No of airplane, the green light will be flashing in 5 seconds, and search to the "FPV\_WIFI\_XXXX" in mobile phone set, so light keeping when WIFI is connected,

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions : (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC RF Radiation Exposure Statement Caution: To maintain compliance with the FCC's RF exposure guidelines, place the product at least 20cm from nearby persons.