


Installing Program

Take the following steps to install the program used for player memory formatting and firmware upgrade.

1. When you insert an installation CD included in the product package into the CD ROM driver, the InstallShield Wizard will start automatically. Press the [Next] button according to the message displayed on the window to complete program installation.



MP3
PLAYER

Installing Program

2. The firmware download and MSCN formatting program will be listed in Start → Programs → MP3 Player mate program group.



Caution

- ▶ Do not connect the player to the PC before installing the program in Windows 98/SE. The program may not work properly.

MP3
PLAYER


Uninstalling Program

You can uninstall the programs used for formatting and firmware upgrade.

1. Select Start → Programs → MP3 Player mate → Uninstall menu.




2. Click the [OK] button when the "Confirm Uninstall" dialog box appears.




Uninstalling Program

3. Lastly, click the [Finish] button to remove the program.




Connecting to a PC

<Connect the player to your PC directly>



<Connect the player using the USB cable>




Warning

▶ Connect the USB cable to the PC after checking the shape of the player's USB connection terminal. If you apply excessive power in inserting the cable, the product or your PC can be damaged seriously.


MP3
PLAYER

Downloading Files

1. Turn the player on and connect to your PC using the USB cable.
2. Wait for a while. Then, the [Removable Disk] item appears in the Explorer folder tree. The saved files will be displayed on the right side window.



3. Open the folder where you have saved MP3 files and select file(s) to download to the player.



MP3
PLAYER

