

HOW TO OPERATE

1. Open BATTERY COMPARTMENT and snap in a 9-volt battery, Replace door firmly.
2. Turn the “ON/OFF” switch to “ON”, and adjust the volume control to normal listening level.
3. Press the “PUSH-TO-TALK” button for transmitting, and speak in a normal voice level into the speaker/microphone grille.
4. Release the “PUSH-TO-TALK” button for receiving.
5. Best transmission and reception are obtained when the FLEXIBLE ANTENNA is held in vertical position.
6. To send MORSE CODE signals, pushing the “PUSH-TO-TALK” button, press the signal code key and quickly release to send a. (dot), or hold key longer to send a-(dash).
7. Use sound had better, volume turn move.

“Modifications not authorized by the manufacturer may void users authority to operate this device.”

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on , the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or and experienced radio/TV technician for help.