

Photo 1: Interior photo of EUT

RF module



Photo 2: Interior photo of EUT


RF module



DVDM800

Photo 3: Interior photo of EUT

RF module



Antenna
Location

DVD800

Photo 4: Interior photo of EUT

RF module




Photo 5: Interior photo of EUT



Photo 6: Interior photo of EUT



DVDM800

Photo 7: Interior photo of EUT




Photo 8: Interior photo of EUT




Photo 9: Interior photo of EUT



Photo 10: Interior photo of EUT



Photo 11: Interior photo of EUT



Photo 12: Interior photo of EUT



Photo 13: Interior photo of EUT



Photo 14: Interior photo of EUT



Photo 15: Interior photo of EUT



Photo 16: Interior photo of EUT




Photo 17: Interior photo of EUT



Photo 18: Interior photo of EUT




Photo 19: Interior photo of EUT




Photo 20: Interior photo of EUT



Photo 21: Interior photo of EUT



Photo 22: Interior photo of EUT



Photo 23: Interior photo of EUT



Photo 24: Interior photo of EUT



Photo 25: Interior photo of EUT




Photo 26: Interior photo of EUT



Photo 27: Interior photo of EUT




Photo 28: Interior photo of EUT



Photo 29: Interior photo of EUT



Photo 30: Interior photo of EUT



Photo 31: Interior photo of EUT

