

hi-call User manual

FCC ID: R2MHI-CALL

Function: Bluetooth Headphone

1 Function Button

Button S1 :

1. To accept a call press briefly the button S1. To end a call press briefly the button S1 during the call.
To reject an incoming call hold the button S1 for 1 second, then release the button. The incoming call is rejected.
2. Press twice (double click) the button S1 to call the last selected number.
3. To activate voice dialing / voiceover / Siri hold the button S1 for 3 seconds from the hi-call; then you can pronounce the command.

Button S2 :

1. To switch on / off hi-call hold the button S2 for 3 seconds.
2. set in pairing mode hold the button S2 for 5 seconds.

2/ LED Indicator

- ① Indication RED LED :
- 1) the LED turns on red-----Charging state
 - 2) indication LED starts flashing red-----Low Voltage
- ② Indication BLUE LED :
- 1) the indication LED flashed alternately red and blue ----- (1) Pair hi-call with a compatible device; (2) incoming call
 - 2) indication LED starts flashing blue slowly every 6 seconds -----the device is paired
 - 3) indication LED flashes alternately red and blue----- set in pairing mode

3. Input Charging Voltage : DC5V

Charge time : 1-2 hours

4. Working time : 5-8 hours

IMPORTANT REGULATORY INFORMATION

This device complies with Part 15 of the FCC Rules: Operation is subject to the following two conditions:

1. This device may not cause harmful interference and
2. This device must accept any interference that is received, including any interference that may cause undesired operation.

WARNING:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.