




# Quick Start Guide



**tracker**  
+ Safe & Found

**Thank you for purchasing Tracker + Safe & Found!** Please follow these simple but important instructions for optimal use of your new tracker.

## 1. Getting to Know Your Tracker




- Power key:** Press and hold the Power key to turn the device on/off. Quickly press 3 times to activate a Family Alert.
- Speaker:** Alert the user with a beep sound when the light sensor detects changes, or when the Find My Device feature is enabled.
- Light sensor:** Ability to detect changes in light.
- Magnetic charging terminals:** Charge your device via the included USB cable and travel adapter.
- LED indicator:** Display the current status.
  - Solid yellow: Battery charging
  - Solid green: Battery fully charged
  - Blinking red: Low battery or alert
  - Blinking green: Pairing mode
  - Solid green for 2s: Paired
  - Solid red: Received Find My Device command
  - No light: Standby

- ## 2. Charging the Battery
- Connect the USB cable to the back of the device. The USB end will be automatically aligned.
  - Once those are aligned, connect the USB end to the travel adapter.
  - Connect the travel adapter to an electrical outlet to fully charge the device.
  - The LED indicator will light up when charging.




- ## 3. Installing the Safe & Found App and Creating A Tracker Account
- If you already have the Sprint Safe & Found app, skip to step 4. If you don't have the Sprint Safe & Found app yet, visit Google Play or App Store to download and install Safe & Found app.



Note: Once Safe & Found is installed, follow the instructions on screen to set up your Safe & Found account.

- ## 4. Connecting Your Tracker to Your Safe & Found Account
- Following these simple steps:
- Click the top-left **Menu**.
  - Tap **Tracker**.
  - Tap **Member** option.
  - Confirm that your tracker is powered on with the green light blinking and tap **Continue**.
  - Give a name to your tracker and add a personalized photo if desired.
  - Tap **Next**.
  - Tap **Continue**.
  - Tap **Continue**.
- Your tracker should now be successfully paired with your Safe & Found account.



- ## 5. More Information
- For more information on device features, how to access advanced app services and personalize your overall experience, visit [www.sprint.com/tracker](http://www.sprint.com/tracker) or [www.coolpad.us](http://www.coolpad.us).
  - For coverage maps check [www.coverage.sprint.com](http://www.coverage.sprint.com).

**Trademarks and Copyrights**  
©2019 Coolpad Technologies Inc. Coolpad and the Coolpad logo are registered trademarks of Yulong Computer Telecommunication Scientific (Shenzhen) Co., Ltd. All rights reserved. Other trademarks and trade names are the property of their respective owners. The product name, logo, design, and appearance of the product are subject to change. Reproduction, transfer, distribution of the contents herein in any manner without the prior written permission of Coolpad Technologies, Inc. is prohibited. Coolpad Technologies, Inc. reserves the right to add, modify or delete any of the contents herein or withdraw the documents at any time without prior notice and without assigning any reason therefor.

©2019 Sprint. All rights reserved. Sprint and the logo are trademarks of Sprint. Other marks are trademarks of their respective owners.