


EdgePoint PRO System Labeling Details



Applies to chassis and external packaging box



Chassis Label Location

MAC ID and Serial # Info on small label that will be able to be read while unit is installed on wall

FCC / Safety Info Label placed on back side of unit close to the power switch

