







GND
RF PWR
MISO1
MOSI1
SCK1
SEN1
CONNECTED
FIFO FULL
READY
DATA ERROR
GND
MOSI0
MISO0
SCK0
CS PD
CS FED
PWR

CN1