



发行
 2007.09.20
 CD

HYT	MODEL Name:	TC980U MCU	Page:	1 of 2
	Date:	2007.09.06	Rev:	D
PCB P/N:	41009801001D0	File No.:		
Layer Name:	Assembly top	SCH No.:		
Layout:	Qinxuqiong	Check:	Cuiyousheng	Approve:



发行
2007.09.20
CD


HYT	MODEL Name:	TC980U MCU	Page:	1 of 2
	Date:	2007.09.06	Rev:	D
PCB P/N:	41009801001D0	File No.:		
Layer Name:	Assembly top	SCH No.:		
Layout:	Qinxuqiong	Check:	Cuiyousheng	Approve:



发行
2007.09.20
CD

2007.09.06
41009801001D0
TC980U MCU VER:D

HYT	MODEL Name:	TC980U MCU	Page:	2 of 2
	Date:	2007.09.06	Rev:	D
PCB P/N:	41009801001D0	File No.:		
Layer Name:	Assembly bottom	SCH No.:		
Layout:	Qinxiaqiong	Check:	Cuiyousheng	Approve:




TC980U RF VER:D
2007.09.06
41009801000D0

20
11
10
J605


GND
RX_IN
TX_OUT
AUX5
AUX7
AUX6
AUX6
RX_OUT
RXD1
TX_IN
TXD1
5GNS
T/R



HYT	MODEL Name:	TC980U RF	Page:	1 of 2
	Date:	2007.09.06	Rev:	D
PCB P/N:	41009801000D0	File No.:		
Layer Name:	Assembly top	SCH No.:		
Layout:	Qinxiaotong	Check:	Cuiyousheng	Approve:



HYT	MODEL Name:	TC980U RF	Page:	2 of 2
	Date:	2007.09.06	Rev:	D
PCB P/N:	41009801000D0	File No.:		
Layer Name:	Assembly bottom	SCH No.:		
Layout:	Qinxiaoliang	Check:	Cuiyousheng	Approve:



发行
2007.09.19
CD

HYT	MODEL Name:	TC980U RF	Page:	2 of 2
	Date:	2007.09.06	Rev:	D
PCB P/N:	41009801000D0	File No.:		
Layer Name:	Assembly bottom	SCH No.:		
Layout:	Qinxiaqing	Check:	Cuiyousheng	Approve: