


Block Diagram : **AMB2300**



Block diagram AMB2300 07/2006

www.amber-wireless.de



AMBER wireless GmbH
Albin-Köbis-Straße 18 • D-51147 Köln • Tel.: +49 (0) 2203-699195-0 • Fax: +49 (0) 2203-459883
Hawstraße 2a • D-54290 Trier • Tel.: +49 (0) 651-99355-0 • Fax: +49 (0) 651-99355-69
www.amber-wireless.de • info@amber-wireless.de

Oscillator frequencies
generated or used
in the device:

: 13.0000MHz (Crystal),
2.402 GHz to 2.480 GHz, 79 channels (operating frequency range)