

Bluetooth speaker

BTS-23

INSTRUCTION MANUAL

**PLEASE READ ALL INSTRUCTIONS
CAREFULLY AND RETAIN FOR FUTURE USE**



Getting started

- Remove the Bluetooth speaker & accessories from the box.
- Remove all packaging from the Bluetooth speaker.
- Place the packaging inside the box to either store or dispose of safely.

In the Box

- Bluetooth Speaker
- USB Charging Cord
- Suction cup
- Instruction Manual

Features

- Enjoy music wirelessly
- Easy to switch between calls and music, you will not miss the incoming call whilst listening to music
- Answer & end a call at click of a button.
- Redial last number
- Volume Control
- Media Control (pause/play, previous track/next track)
- Every time the Bluetooth speaker is turned on, it

connects to last connected device automatically


- Auto scan FM radio

Safety Instructions

Read this manual carefully before putting the appliance into operation and keep this manual for future reference.

- Do not insert any metal object into the device.
- To avoid a static charge, do not use the device in an extremely dry climate.
- Do not attempt to repair the device yourself.
- Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.

Description of Parts



1	Power ON/OFF button
2	LED indicator
3	NEXT / VOL+ button
4	PREV / VOL- button
5	Phone button
6	Mode, switch between Bluetooth and FM radio
7	Play/Pause button
8	Built-in microphone hole
9	Micro USB charging port

Charging Instructions

This Bluetooth speaker comes with a built in rechargeable battery. Before using it for the first time we recommend you charge the battery fully. Only use the supplied USB cable to charge the Bluetooth speaker.

1. Connect the USB cable to the USB port on the unit.
2. Connect the other end of the USB cable to a USB port on a PC or an AC/DC adapter. The LED indicator turns on to indicate that the battery is being charged. When the battery is fully charged, the LED indicator will turn off.

Pairing the Bluetooth speaker with Bluetooth devices (phone or music device)

1. Turn off the speaker. Make sure the speaker is power off before going to the next step.
2. Press and hold the Power button for about 3 seconds, then release. The LED light flashes, now the Bluetooth speaker is ready for pairing.
3. Turn on your Bluetooth enabled device and activate the Bluetooth function.
4. Search for the Bluetooth device, "BTS-23" will

show up.

5. Pair your Bluetooth enabled device with BTS-23. If a password is needed, type in "0000". After the BTS-23 is paired with your device, connect it to your device.

Tips:

Once the speaker is paired and connected to your Bluetooth device, it automatically connect the next time as long as the Bluetooth on your device is turned on.

Control a phone call via speaker

Answer a call: Short press the Phone button.

End a call: Short press the Phone button.

Reject a call: Press and hold the Phone button for around 2 seconds.

Redial the last number: Press the phone button twice quickly.

How to use the FM radio

This Bluetooth speaker comes with a FM radio. Button function is as below:

Mode: Switch between Bluetooth and FM radio.

⏪ Short press to choose radio station, long press to reduce volume.

⏩ Short press to choose radio station, long press to increase volume.

Specifications

Bluetooth profiles	HSP, HFP, A2DP and AVRCP
Bluetooth operating distance	10 meters (equal to 33 feet)
Frequency range	2.4-2.48GHz
Frequency response	100Hz-20kHz
FM frequency	87.5-108 MHz
Distortion	≤1%
Microphone sensitivity	-40db
Working time	Music time 4 hours, talk time 6 hours
Charging input power	DC 5V
Charging time	Approx 3 hours
Unit size	109*74*26 mm
Unit weight	Approx. 180g
IP grade	IPx4 (Splashproof)

Note: Battery life & charging time may vary, based on usage & types of devices used.

FCC Statement:

This equipment has been tested and found to comply with the limits for Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: Modifications to this product will void the user's authority to operate this equipment.

