

Bluetooth Speaker

USER MANUAL

Model No.: BTS-C08



Dear Customer,

Thanks for purchasing our product!

Please kindly read this user manual before using the product carefully, and keep it for future reference.



Safety Instructions

- Please read these instructions before using the product.
- Do not insert any metal object into the device.
- To avoid a static charge, do not use the device in an extremely dry climate.
- Do not attempt to open or repair the device by yourself.
- Avoid heavy shocks to the product and do not drop it.
- Batteries (battery pack or batteries installed) shall not be exposed to over heat condition like sunshine or fire.

Package:

1. Bluetooth Speaker: x 1
2. Micro USB Charging Cable: x 1
3. AUX input cable: x 1
4. User Manual: x 1

INSTRUCTION OF PRODUCT PANEL AND BACK PANEL



1. MODE
2. PREV/VOL-
3. PREV/VOL+
4. Play/Pause/Phone
5. AUX port
6. USB Slot
7. TF Card Slot
8. Charging Port
9. LED Indicator

OPERATIONS:

Connection Bluetooth Function

1. Make sure the Bluetooth speaker and Bluetooth® enabled device is within 1 meter during pairing.
2. Long press “mode” button of product to turn on/off the unit, LED indicator flashes quickly in Blue on the back of product once turned on, and the speaker enter into Bluetooth mode.
3. Open your Bluetooth® enabled device, search for “BTS-C08”, and select it to connect the product to your Bluetooth® enabled device. After connected successfully, LED indicator will keep lighting up in blue color. Then keep flashing slowly when playing the music.
4. Depending on the Bluetooth® enabled device which you are trying to connect it to the speaker, it may be necessary to type a pass code. Please type “0000” if you are prompted by the device. Your Bluetooth® enabled device will confirm that the pairing was completed, and remind you to accept the connection. Please respond YES to connect the product to your Bluetooth® enabled device.

Note : When you turn on and switch the Bluetooth Speaker to Bluetooth Mode, it will automatically connect to the paired Bluetooth® enable device if they are in the required range.

Using Bluetooth Speaker

1. Playing Music of Bluetooth® enabled device

Connect your Bluetooth® Speaker to Bluetooth® enabled device following above steps. After connected successfully, you can press “PLAY” on your Bluetooth® device or “Play/Pause” button on the top side of product to play/pause the song. Long press “NEXT/VOL+” or “PREV/VOL-” to increase or decrease the volume. Short press “NEXT/VOL+” or “PREV/VOL-” to select next or previous song.

Note : You may also adjust the volume from your Bluetooth® enabled device's volume control.

2. Listen to USB/TF card

Insert USB card / TF card into the USB / TF port of speaker, the unit will play the song of USB card/TF card automatically. Short press “Play/Pause” button on the top side of product to play/pause the song. Long press “NEXT/VOL+” or “PREV/VOL-” to increase or decrease the volume. Short press “NEXT/VOL+” or “PREV/VOL-” to select next or previous song.

3. Listen to AUX function

Connect one end of AUX cable to the Bluetooth speaker and the other end to the

audio device. The speaker will play the song automatically. Short press "Play/Pause" button on the top side of product to play/pause the song. Long press "NEXT/VOL+" or "PREV/VOL-" to increase or decrease the volume. Short press "NEXT/VOL+" or "PREV/VOL-" to select next or previous song.

4. Listen to FM function.

Insert the Micro USB end of USB rechargeable cable into the charging port, and leave the other end of the cable open. USB rechargeable cable serves as FM Antenna while in FM Radio mode.

Short press "MODE" button on front panel of the unit to enter into FM mode. Short press "Play/Pause" to search and memorize FM channels automatically, the Led indicator flashes quickly, then it will flash slowly when playing the sound of a FM channel. Long press "NEXT/VOL+" or "PREV/VOL-" to increase or decrease the volume, short press "NEXT/VOL+" or "PREV/VOL-" to select next or previous channel.

Telephone Function

Note : You may answer & end call while listening to music. The music will stop when a call is answered, and will restart when the call is ended.

To answer a call : Short press the "Mode" button

To end a call : Short press the "Mode" button again.

To reject a call : Press and hold the "Mode" button for about 2 seconds.

To make a new call : Dial the number and press the SEND button on your mobile phone, the call is automatically transferred to the speaker.

To redial the last number called : Press the "Mode" button twice quickly. The last number called will be redialed.

Charging The Bluetooth® Speaker

Connect the micro USB jack of USB charging cable to the USB port of speaker, and the other end to your computer's USB port or an USB wall charger (not included), The LED indicator will light up in RED, indicating the battery is being charged. When the speaker is fully charged, the LED indicator will light off (Approx. 3 hours).

TECHNICAL SPECIFICATIONS

Bluetooth® version	: V 4.2
Working distance	: Up to 10 meters in open space
FM Frequency response	: 87.5 Hz – 108Mhz
Output power	: 2 x 3 W
Battery Capacity	: 1200 mAh
Distortion	: \leq 1.0%
Microphone sensitivity	: - 40 dB
Playback time	: Music time 2 - 3 hours
Charging input power	: DC 5 V (micro USB)
Charging time	: Approx. 4 - 5 hours
Unit size	: L6-3/16" x H9-1/8" x D2-1/8"
Unit weight	: approx. 600 g

Note: Battery life & charging time may vary, based on usage & types of devices used.
The product design and specifications may be changed subject of without prior notice!

Warning Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.