


5F, No.81, Sec.1, Sintai 5th. Rd., Sijhih, New Taipei City 22101, Taiwan.

User's Manual

Product Name: Remote control for ceiling fan 7RC04-CF000007

FCC ID: R8Y7RC04-CF000007



The Remote control buttons are defined below:

- Six-Speed Buttons-No.1 is the highest speed, No.6 is the lowest speed
- ON/OFF Button-Light turn on/turn off
- F/R Button-forward/reverse from rotation
- ON/OFF Red Button-Power turn on/turn off

Operating remote control:

Install two 1.5 volt batteries into the hand-held remote control. Press any speed button to start fan operation.

Note: If not using for long period of time, remove batteries to prevent damage of remote control. Store the remote control away from human body.

Operating Frequency: 2407 MHz. 2440 MHz. 2475 MHz

Modulation type: GFSK

Warming !

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment.

"This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation."

寰宇電控股份有限公司 Pan-World Control Technologies, Inc.

5F, No.81, Sec.1, Sintai 5th. Rd., Sijhih, New Taipei City 22101, Taiwan.

President: Ben Tsai mail: bentsai@pwctek.com.tw

Specialist: Eric yen mail: ericyen822002@pwctek.com.tw