




802.11g CHANNEL 2, SPURIOUS 30 MHz ~ 3 GHz




802.11g CHANNEL 2, SPURIOUS 2 GHz ~ 25 GHz




802.11g CHANNEL 6 CARRIER LEVEL




802.11g CHANNEL 6, SPURIOUS 30 MHz ~ 3 GHz




802.11g CHANNEL 6, SPURIOUS 2 GHz ~ 25 GHz




### 802.11g CHANNEL 11 CARRIER LEVEL




### 802.11g CHANNEL 11, SPURIOUS 30 MHz ~ 3 GHz




### 802.11g CHANNEL 11, SPURIOUS 2 GHz ~ 25 GHz




### 802.11n-20 CHANNEL 1 CARRIER LEVEL




802.11n-20 CHANNEL 1, SPURIOUS  
30 MHz ~ 3 GHz




802.11n-20 CHANNEL 1, SPURIOUS  
2 GHz ~ 25 GHz




802.11n-20 CHANNEL 2 CARRIER LEVEL




802.11n-20 CHANNEL 2, SPURIOUS  
30 MHz ~ 3 GHz




802.11n-20 CHANNEL 2, SPURIOUS  
2 GHz ~ 25 GHz



802.11n-20 CHANNEL 6 CARRIER LEVEL



802.11n-20 CHANNEL 6, SPURIOUS  
30 MHz ~ 3 GHz




802.11n-20 CHANNEL 6, SPURIOUS  
2 GHz ~ 25 GHz




802.11n-20 CHANNEL 10 CARRIER LEVEL




802.11n-20 CHANNEL 10, SPURIOUS  
30 MHz ~ 3 GHz




802.11n-20 CHANNEL 10, SPURIOUS  
2 GHz ~ 25 GHz



802.11n-20 CHANNEL 11 CARRIER LEVEL




802.11n-20 CHANNEL 11, SPURIOUS  
30 MHz ~ 3 GHz




802.11n-20 CHANNEL 11, SPURIOUS  
2 GHz ~ 25 GHz




### 802.11n-40 CHANNEL 3 CARRIER LEVEL




### 802.11n-40 CHANNEL 3, SPURIOUS 30 MHz ~ 3 GHz




### 802.11n-40 CHANNEL 3, SPURIOUS 2 GHz ~ 25 GHz




### 802.11n-40 CHANNEL 4 CARRIER LEVEL




802.11n-40 CHANNEL 4, SPURIOUS  
30 MHz ~ 3 GHz




802.11n-40 CHANNEL 4, SPURIOUS  
2 GHz ~ 25 GHz



802.11n-40 CHANNEL 6 CARRIER LEVEL



802.11n-40 CHANNEL 6, SPURIOUS  
30 MHz ~ 3 GHz




802.11n-40 CHANNEL 6, SPURIOUS  
2 GHz ~ 25 GHz







### 802.11n-40 CHANNEL 7 CARRIER LEVEL




### 802.11n-40 CHANNEL 7, SPURIOUS 30 MHz ~ 3 GHz



### 802.11n-40 CHANNEL 7, SPURIOUS 2 GHz ~ 25 GHz




### 802.11n-40 CHANNEL 8 CARRIER LEVEL







802.11n-40 CHANNEL 8, SPURIOUS  
30 MHz ~ 3 GHz




802.11n-40 CHANNEL 8, SPURIOUS  
2 GHz ~ 25 GHz




802.11n-40 CHANNEL 9 CARRIER LEVEL




802.11n-40 CHANNEL 9, SPURIOUS  
30 MHz ~ 3 GHz




802.11n-40 CHANNEL 9, SPURIOUS  
2 GHz ~ 25 GHz




### 802.11ac-20 CHANNEL 1 CARRIER LEVEL



### 802.11ac-20 CHANNEL 1, SPURIOUS 30 MHz ~ 3 GHz



### 802.11ac-20 CHANNEL 1, SPURIOUS 2 GHz ~ 25 GHz



### 802.11ac-20 CHANNEL 2 CARRIER LEVEL

